


# Quick Start Guide

**TWR-MECH**  
Mechatronics Board



**TOWER SYSTEM**

# Get to Know the Tower Mechatronics Board



# How to Use the Mechatronics Robot

The Freescale robot (FSLBOT) kit operates with the Tower mechatronics (TWR-MECH) board to create an easy-to-use mechatronics development and demonstration platform. It is designed specifically to be used and programmed with StickOS® BASIC. More advanced users can take programming to new levels of functionality with the use of CodeWarrior and Freescale's Tower System.



## TWR-MECH BOARD

### Freescale Tower System


The TWR-MECH board is part of the Freescale Tower System, a modular development platform that enables rapid prototyping and tool re-use through reconfigurable hardware. Take your design to the next level and begin constructing your Tower System today.

# Step-by-Step Installation Instructions for StickOS

StickOS BASIC is a programming language and an IDE. It's specifically designed to allow those with little or no programming experience to get up and running quickly with the TWR-MECH board. It also provides complex functionality such as vision filters and face tracking.

## 1 Install StickOS

1. Open an Internet browser of your choice and navigate to **freescale.com/mechbot**



2. Select the "Download" tab. Scroll through the list of downloads and select FSLBOT\_StickOS\_IDE. Click "Download" and save the file to an easily accessible place on your computer.
3. Decompress the downloaded file.

## 2 Connect the USB Cable

1. Plug the included FSLBOT USB cable into the computer and into the left rear mini-USB port on the board (labeled USB OTG).
2. The “Found New Hardware Wizard” will appear. Choose “Install” from a list or specific location (Advanced). Click “Next.”




## 3 Configure Drivers with Windows® XP

1. Ensure “Search for the best driver in these locations” is selected. Also, the “Include this location in the search” box should be checked. Click “Browse” and navigate to the folder of the recently downloaded file. Click “OK,” followed by “Next.”



2. The hardware wizard will install the needed files to run the Freescale TWR-MECH.
3. Once the hardware wizard has finished, click “Finish” to complete the installation.



## Additional Resources

For more information, visit  
[freescale.com/mechbot](http://freescale.com/mechbot).

Join the online Tower community at  
[towergeeks.org](http://towergeeks.org).

# Installation Instructions for CodeWarrior

## 1 Install CodeWarrior

- Download and install the latest version of CodeWarrior for ColdFire V2 from **freescaler.com**.
- Download the CodeWarrior sample code for the Freescale mechatronics robot. This can be found on the Freescale website on the right hand side of the TWR-MECH page under “**Featured Software**.”

## 2 Connect the USB Cable

Connect the USB cable to the PC and the other end to the J17 on the TWR-MECH board, also labeled “DEBUG.”

## 3 Configure Drivers

Allow PC to automatically configure drivers if needed. If you have driver problems, please see the TWR-MECH driver installation guide located in the sample code folder mentioned above, or visit **pemicro.com/osbdm**.

## 4 Launch Software

Launch CodeWarrior for ColdFire V2. Close the startup box, and click “**File > Open**” to open the sample code.

The file path is: **TWR\_MECH\_FSLBOT\_Cadewarrior\_Sample\_CODE/ mcf5225x\_SC\_FreeBot/build/cw/twr-mcf5225x/TWR\_Mechatronics\_MCF5225X\_base.mcp**.

You are now ready to start programming with CodeWarrior.

Note: On/Off switch must be in “**On**” position for the servos to activate.

## Additional Resources

Please see the related documents provided in the sample code folder, and visit **freescaler.com** for more information.

# TWR-S08PT60 Default Jumper Options

The following is a list of all jumper options. The default installed jumper settings are shown in white text within the violet boxes.

| Jumper | Option                                 | Setting       | Description   |
|--------|--|---------------|---|
| J3     | Default Clock Mode Selection (CLKMOD1) | 1-2           | Disable PLL at startup  |
|        |  | 2-3           | Enable PLL at startup   |
| J4     | MCU Power Connection                   | On Cut-Trace  | Supply 3.3V to MCU  |
|        |  | Off           | Isolate MCU from power (connect an ammeter to measure current)  |
| J5     | Clock Input Source Selection           | 1-2           | Connect EXTAL to the on-board crystal   |
|        |  | 2-3           | Connect EXTAL to the CLKIN0 signal on the elevator connector  |
| J6     | Default Clock Mode Selection (CLKMOD0) | 1-2           | Do not use crystal oscillator at startup  |
|        |  | 2-3           | Use crystal oscillator at startup   |
| J7     | Potentiometer Selection                | On Cut-Trace  | Connect AN6 to potentiometer  |
|        |  | Off           | Isolate AN6 from potentiometer  |
| J8     | Serial Flash Programming Mode          | 1-2 Cut-Trace | Pull RCON high, allow normal reset behavior   |
|        |  | 2-3           | Pull RCON low, as exiting reset give EzPort access to flash memory for programming by external device |
| J10    | Default Clock Mode Selection (XTAL)    | 1-2           | Bypass crystal oscillator at startup (if CLKMOD0 = 0)   |
|        |  | 2-3           | Enable internal relaxation oscillator at startup (if CLKMOD0 = 0)                                     |
|        |  | Off           | Use crystal oscillator at startup   |



TWR-MECH Jumper Options (*continued*)

| Jumper | Option                                 | Setting          | Description  |
|--------|--|------------------|--|
| J11    | UART Hardware Flow Control Connections | 1-2              | Connect CTS0 to the RS232 transceiver for flow control                   |
|        |  | 3-4              | Connect RTS0 to the RS232 transceiver for flow control                   |
| J12    | UART TXD0 Routing Selection            | 1-2              | Connect TXD0 to the RS232 transceiver                                    |
|        |  | 2-3              | Connect TXD0 to the OSBDM debugger interface circuit                     |
| J13    | UART RXD0 Routing Selection            | 1-2              | Connect RXD0 to the transceiver  |
|        |  | 2-3              | Connect RXD0 to the OSBDM debugger interface circuit                     |
| J14    | BDM/JTAG Enable Selection              | 1-2<br>Cut-Trace | BDM mode   |
|        |  | 2-3              | JTAG mode  |
| J15    | TCLK/PSTCLK Routing Selection          | 1-2              | Connect TCLK/PSTCLK to PSTCLK for BDM mode                               |
|        |  | 2-3              | Connect TCLK/PSTCLK to TCLK for JTAG                                     |
| J16    | TCLK/PSTCLK/CLKOUT Routing Selection   | 1-2              | Connect TCLK/PSTCLK/CLKOUT to TCLK/PSTCLK for BDM/JTAG mode              |
|        |  | 2-3              | Connect TCLK/PSTCLK/CLKOUT to CLKOUT0 on the elevation connector         |
| J20    | OSBDM Bootloader Selection             | On               | OSBDM bootloader mode (OSBDM firmware reprogramming)                     |
|        |  | Off<br>Non-Pop   | Debugger mode  |
| J21    | RESET Select                           | On               | Suspend MCU in reset state (hold RSTIN low)                              |
|        |  | Off<br>Non-Pop   | Release RSTIN so it can be controlled by SW4 to initiate reset sequences |

TWR-MECH Jumper Options (*continued*)

| Jumper | Option  | Setting       | Description   |
|--------|---|---------------|---|
| J22    | Servo Motor Signal Selection                  | 1-2           | Connect SERVO_1 PWM signal to servo plug                  |
|        |   | 3-4           | Connect SERVO_2 PWM signal to servo plug                  |
|        |   | 5-6           | Connect SERVO_3 PWM signal to servo plug                  |
|        |   | 7-8           | Connect SERVO_4 PWM signal to servo plug                  |
|        |   | 9-10          | Connect SERVO_5 PWM signal to servo plug                  |
|        |   | 11-12         | Connect SERVO_6 PWM signal to servo plug                  |
|        |   | 13-14         | Connect SERVO_7 PWM signal to servo plug                  |
|        |   | 15-16         | Connect SERVO_8 PWM signal to servo plug                  |
| J40    | Touch Sensor Interrupt Select                 | On Cut-Trace  | Connect IRQ_TOUCH to IRQ7_b to use touch sensor interrupt |
|        |   | Off           | Isolate IRQ7_b from touch sensor                          |
| J41    | Universal Sensor No. 1 Interrupt No. 1 Select | On            | Connect AN0 to IRQ1_b to sense interrupt signal           |
|        |   | Off           | Isolate AN0 from IRQ1_b to measure analog signal          |
| J42    | Universal Sensor No. 1 Interrupt No. 2 Select | On            | Connect AN1 to IRQ3_b/FEC_MDIO to sense interrupt signal  |
|        |   | Off           | Isolate AN1 from IRQ3_b/FEC_MDIO to measure analog signal |
| J43    | Universal Sensor No. 1 Interrupt No. 3 Select | On            | Connect AN2 to IRQ5_b/FEC_MDC to sense interrupt signal   |
|        |   | Off           | Isolate AN2 from IRQ5_b/FEC_MDC to measure analog signal  |
| J49    | Battery Selection                             | 1-2 Cut-Trace | Connect SW1 to BAT1 for 4x AA cells                       |
|        |   | 2-3           | Connect SW1 to BAT2 for 7.2V external battery pack        |





For more information, visit

[freescale.com/Tower](http://freescale.com/Tower)

Join the online Tower community at

[towergeeks.org](http://towergeeks.org)

Freescale, the Freescale logo, CodeWarrior and ColdFire are trademarks or registered trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. © 2011 Freescale Semiconductor, Inc.



**Стандарт  
Электрон  
Связь**

Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию .

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России , а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научно-исследовательскими институтами России.

С нами вы становитесь еще успешнее!

**Наши контакты:**

**Телефон:** +7 812 627 14 35

**Электронная почта:** [sales@st-electron.ru](mailto:sales@st-electron.ru)

**Адрес:** 198099, Санкт-Петербург,  
Промышленная ул, дом № 19, литера Н,  
помещение 100-Н Офис 331