

# MCP651 Input Offset Evaluation Board User's Guide

© 2009 Microchip Technology Inc.

#### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION. QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

## QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2002

#### Trademarks

The Microchip name and logo, the Microchip logo, Accuron, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, rfPIC, SmartShunt and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL, SmartSensor and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, In-Circuit Serial Programming, ICSP, ICEPIC, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, nanoWatt XLP, PICkit, PICDEM, PICDEM.net, PICtail, PIC<sup>32</sup> logo, PowerCal, PowerInfo, PowerMate, PowerTool, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2009, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



## MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE

## **Table of Contents**

Preface	1
Introduction	1
Document Layout	1
Conventions Used in this Guide	2
Recommended Reading	3
The Microchip Web Site	3
Customer Support	3
Document Revision History	4
Chapter 1. Product Overview	
1.1 Introduction	5
1.2 Kit Contents	
1.3 Intended Use	
1.4 Description	Ċ
Chapter 2. Installation and Operation	
2.1 Introduction	
2.3 Configuring the Lab Equipment and PCB	
2.4 Operating Conditions	
2.5 Converting to Other Parameters	
2.6 Settling Time, Noise and Sampling Rate	7
Chapter 3. Possible Modifications	
3.1 Introduction19	
3.2 Range of Parts Supported by MCP651 Input Offset Evaluation Board 19	
3.3 Changes to Accommodate Other DUTs	1
Appendix A. Schematics and Layouts	_
A.1 Introduction	
A.2 Schematic and Layouts	
A.3 Board – Schematic	
Layers	
A.5 Board – Top Silk Screen	
A.6 Board – Top Solder Mask and Top Metal Layer	
A.7 Board – Bottom Metal Layer	J

Appendix B. Bill Of Materials (BOM)	
B.1 MCP651 Input Offset Evaluation Board BOM	31
B.2 Adaptor Board BOM	33
Worldwide Sales and Service	34



## MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE

## Preface

## NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our web site (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a "DS" number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is "DSXXXXA", where "XXXXX" is the document number and "A" is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB<sup>®</sup> IDE on-line help. Select the Help menu, and then Topics to open a list of available on-line help files.

## INTRODUCTION

This chapter contains general information that will be useful to know before using the MCP651 Input Offset Evaluation Board. Items discussed in this chapter include:

- Document Layout
- Conventions Used in this Guide
- Recommended Reading
- The Microchip Web Site
- Customer Support
- Document Revision History

## DOCUMENT LAYOUT

This document describes how to use the MCP651 Input Offset Evaluation Board. The manual layout is as follows:

- Chapter 1. "Product Overview" Important information about the MCP651 Input Offset Evaluation Board.
- Chapter 2. "Installation and Operation" Covers the initial set-up of the MCP651 Input Offset Evaluation Board. It lists the required tools, shows how to set up the board and how to connect lab equipment. It then demonstrates how to use this board.
- Chapter 3. "Possible Modifications" Shows how to modify the board for other single Microchip op amps in SOIC-8, PDIP-8 and other packages.
- **Appendix A. "Schematics and Layouts"** Shows the schematic and board layouts for the MCP651 Input Offset Evaluation Board.
- Appendix B. "Bill Of Materials (BOM)" Lists the parts used to populate the MCP651 Input Offset Evaluation Board. Also lists loose parts shipped with the board in an ESD bag, alternate components and components not populated.

## **CONVENTIONS USED IN THIS GUIDE**

This manual uses the following documentation conventions:

### **DOCUMENTATION CONVENTIONS**

Description	Represents	Examples
Arial font:		
Italic characters	Referenced books	MPLAB <sup>®</sup> IDE User's Guide
	Emphasized text	is the only compiler
Initial caps	A window	the Output window
	A dialog	the Settings dialog
	A menu selection	select Enable Programmer
Quotes	A field name in a window or dialog	"Save project before build"
Underlined, italic text with right angle bracket	A menu path	<u>File&gt;Save</u>
Bold characters	A dialog button	Click OK
	A tab	Click the <b>Power</b> tab
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1
Text in angle brackets < >	A key on the keyboard	Press <enter>, <f1></f1></enter>
Courier New font:		
Plain Courier New	Sample source code	#define START
	Filenames	autoexec.bat
	File paths	c:\mcc18\h
	Keywords	_asm, _endasm, static
	Command-line options	-Opa+, -Opa-
	Bit values	0, 1
	Constants	OxFF, `A'
Italic Courier New	A variable argument	<i>file.o</i> , where <i>file</i> can be any valid filename
Square brackets [ ]	Optional arguments	<pre>mcc18 [options] file [options]</pre>
Curly brackets and pipe character: {   }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}
Ellipses	Replaces repeated text	<pre>var_name [, var_name]</pre>
	Represents code supplied by user	<pre>void main (void) { }</pre>

### **RECOMMENDED READING**

This user's guide describes how to use MCP651 Input Offset Evaluation Board. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources.

### MCP6V01/2/3 Data Sheet, "300 µA, Auto-Zeroed Op Amps", DS22058

Gives detailed information on the op amp family that is used for signal processing and output voltage control on the MCP651 Input Offset Evaluation Board.

#### MCP651 Data Sheet, "5 mA Op Amps with mCal", DS22146

Gives detailed information on the op amp family that is used as the DUT on the MCP651 Input Offset Evaluation Board.

#### AN1177 Application Note, "Op Amp Precision Design: DC Errors", DS01177

Discusses how to achieve high DC accuracy in op amp circuits. Also discusses the relationship between an op amp's input offset voltage ( $V_{OS}$ ), CMRR, PSRR, Open-Loop Gain and  $V_{OS}$  Drift over Temperature.

## AN1258 Application Note, "Op Amp Precision Design: PCB Layout Techniques", DS01258

Discusses how to lay out PCBs for high DC accuracy in op amp circuits. Also discusses other PCB related accuracy issues.

#### 8-Pin SOIC/MSOP/TSSOP/DIP Evaluation Board User's Guide, DS51544

Covers the usage of the SOIC8EV Evaluation Board.

### THE MICROCHIP WEB SITE

Microchip provides online support via our web site at www.microchip.com. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- Product Support Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- General Technical Support Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

#### **CUSTOMER SUPPORT**

Users of Microchip products can receive assistance through several channels:

- · Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- · Technical Support
- · Development Systems Information Line

Customers should contact their distributor, representative or field application engineer for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: http://support.microchip.com

## **DOCUMENT REVISION HISTORY**

## Revision A (May 2009)

• Initial Release of this Document.



## **MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE**

## **Chapter 1. Product Overview**

#### 1.1 INTRODUCTION

The MCP651 Input Offset Evaluation Board is described by the following:

- Assembly #: 102-00258-R2
- Order #: MCP651EV-VOS
- Name: MCP651 Input Offset Evaluation Board

Items discussed in this chapter include:

- Kit Contents
- Intended Use
- Description

#### 1.2 **KIT CONTENTS**

- One MCP651 Input Offset Evaluation Board, 102-00258-R2
- Important Information "Read First"



FIGURE 1-1:

MCP651 Input Offset Evaluation Board Kit Contents.

## 1.3 INTENDED USE

The MCP651 Input Offset Evaluation Board is intended to provide a simple means to measure the MCP651 Input Offset Evaluation Board op amp's input offset voltage under a variety of operating conditions. The measured input offset voltage ( $V_{OST}$ ) includes the input offset voltage specified in the data sheet ( $V_{OS}$ ) plus changes due to: power supply voltage (PSRR), common mode voltage (CMRR), output voltage ( $A_{OL}$ ), input offset voltage drift over temperature ( $\Delta V_{OS}/\Delta T_A$ ) and 1/f noise.

The MCP651 Input Offset Evaluation Board works most effectively at room temperature (near 25°C). Measurements at other temperatures should be done in an oven where the air velocity is minimal.

## 1.4 DESCRIPTION

This section starts with the conversion of DUT bias voltages described in the MCP651 data sheet to the voltages on this board. Then there is a discussion of the circuitry that controls the DUT's output voltage ( $V_{OUTX}$ ) and amplifies its total input offset voltage ( $V_{OST}$ ). Finally, other portions of the circuit, and their purpose, are discussed. Complete details of this board are given in **Appendix A. "Schematics and Layouts"** and **Appendix B. "Bill Of Materials (BOM)**".

### 1.4.1 Conversion of Bias Voltages

The MCP651 data sheet describes all of its bias voltages relative to  $V_{SS}$ , which is assumed to be at ground (0V). On the other hand, the MCP651 Input Offset Evaluation Board sets the DUT's input common mode voltage to 0V. The user needs to convert from the first set of voltages to the second set (by subtracting  $V_{CM}$ ):

Data Sheet Bias Voltage (V)	Conversion Equations	Evaluation Board Bias Voltage (V)
V <sub>CM</sub>	V <sub>CM</sub> – V <sub>CM</sub>	V <sub>CMX</sub> = 0V
V <sub>DD</sub>	$V_{DD} - V_{CM}$	V <sub>DDI</sub>
V <sub>SS</sub>	$V_{SS} - V_{CM}$	V <sub>SSI</sub>
V <sub>OUT</sub>	V <sub>OUT</sub> – V <sub>CM</sub>	V <sub>OUTX</sub>
VL	$V_L - V_{CM}$	V <sub>LX</sub>
V <sub>CAL</sub>	$V_{CAL} - V_{CM}$	V <sub>CALX</sub>

#### TABLE 1-1: CONVERSION OF BIAS VOLTAGES

The supply voltages  $V_{DDX}$  and  $V_{SSX}$  can be estimated using the MCP651's typical quiescent current (I<sub>Q</sub> = 6 mA):

#### EQUATION 1-1:

$$\begin{split} V_{DDX} &= V_{DDI} + I_{\underline{Q}}(10\,\Omega) \approx V_{DDI} + 60 \ mV \\ V_{SSX} &= V_{SSI} - I_{\underline{Q}}(10\,\Omega) \approx V_{SSI} - 60 \ mV \end{split}$$

### 1.4.2 Simplified Circuit and Operation

Figure 1-2 is a simplified diagram of the circuitry that biases the DUT and produces an amplified version of the DUT's input offset voltage ( $V_{OST}$ ). It includes gain at the input, a Proportional plus Integral (PI) controller loop, a high gain amplifier and a filter.



FIGURE 1-2: Simplified Circuit.

The elements of Figure 1-2 correspond to the components in the complete schematic (**A.3 "Board – Schematic"**) as follows.

#### TABLE 1-2: CONVERSION OF SCHEMATIC COMPONENTS

Complete Schematic ComponentsSimplified Schematic Component		Conversion Equations	Typical Values (Note 1)
R1, R2	R <sub>12</sub>	= R1    R2	≈ 196.1Ω
R3	R <sub>3</sub>	= R3	≈ <b>200</b> .0Ω
R4	R <sub>4</sub>	= R4	≈ 10.00 kΩ
R5, R6	R <sub>56</sub>	= R5 + R6	≈ 8.04 kΩ
R7, R8	R <sub>78</sub>	= R7 + R8	$\approx$ 40.0 k $\Omega$
C2	C <sub>2</sub>	= C2	≈ 22 nF
U1	"DUT"		—
U2	"+1 Buffer"	—	—
R11, R12	"1/G <sub>INT</sub> "	= R11 / (R11 + R12)	≈ 1 / (3.213 V/V)
R13, R14		= R13 / (R13 + R14)	≈ 1 / (3.213 V/V)
U3, R11, R12, C6	"Integrator (ω <sub>INT</sub> /s)"	ω <sub>INT</sub> = 1 / ((R11    R12)C6)	≈ 2π (10.3 Hz)
U3, R17, C7		ω <sub>INT</sub> = 1 / (R17 · C7)	≈ 2π (10.4 Hz)
U4, R23, R24, R25, R26, S2	"G <sub>M</sub> "	= 1 + R24 / R23	$\approx$ 3.941 V/V, S2 closed
		= 1 + (R24 + R25 + R26) / R23	≈ 39.18 V/V, S2 open
R28, C12	"Lowpass Filter ( $\omega_{BW}$ )"	ω <sub>BW</sub> = 1 / (R28 · C12)	≈ 2π (1.59 Hz)

Note 1: Switch S2's top position is closed when to the right (LOW GAIN), and is open when to the left (HI GAIN).

Analysis of this simplified circuit gives the following nominal circuit outputs:

 $V_{OUTX} \approx V_{COX}$  $V_M \approx G_A G_M V_{OST}$ 

#### EQUATION 1-2:

Where:

 $\begin{array}{rcl} G_A &=& 1 + R4/R3 \approx 51.00 \ V/V \\ G_A G_M &\approx& 201.0 \ V/V, & S2 \ (\text{position 1}) \ \text{closed} \\ &\approx& 1998 \ V/V, & S2 \ (\text{position 1}) \ \text{open} \end{array}$ 

 $R_1$  and  $R_2~(R_{12})$  balance the circuit at the DUT's input. These resistors are small, and are oriented on the Printed Circuit Board (PCB) to cancel their thermoelectric voltages. The parallel resistances  $R_1||R_2$  and  $R_3||R_4$  are equal to minimize the contribution of the DUT's input bias currents to the measured  $V_{OST}$  (contributions by  $R_5$  through  $R_8$  do not affect  $V_M$ ); the typical value of  $I_{OS}$  at +125°C is ±100 pA, which produces a change in  $V_{OST}$  of ±0.02  $\mu V.$ 

The unity gain buffer (+1 gain on the bottom right) isolates the V<sub>COX</sub> input filters from the following attenuator and integrator. Although it's not shown here, the resistor R14 at the input to the "+1 Buffer" ensures its output voltage is 0V when the V<sub>COX</sub> connector is left open.

The attenuators (1/G<sub>INT</sub>) scale V<sub>COX</sub> and V<sub>OUTX</sub> so that they do not overdrive op amps U2 and U3 ("+1 Buffer" and ("Integrator"). For instance, when V<sub>OUTX</sub> = 5.6V (given V<sub>SSI</sub> =0.3V and V<sub>DDI</sub> = 5.8V), the voltages at the outputs of the attenuators (1/G<sub>INT</sub>) is 1.80V.

The differential integrator accumulates the scaled difference between V<sub>COX</sub> and V<sub>OUTX</sub>, which slowly forces this difference to zero (the I part of the PI controller). Resistor R<sub>56</sub> injects the integrator's output at the DUT's input through resistors R<sub>4</sub> and R<sub>3</sub>; it minimizes the error at V<sub>OUTX</sub>.

A proportional term (the P part of the PI controller) is also injected at the DUT's input through resistor  $R_{78}$ ; it stabilizes the control loop (the integrator term becomes negligible above 16 Hz). It also sets a low frequency DUT noise gain of about 505 V/V. This proportional term is rolled off by  $C_2$  starting at 0.18 kHz; this is high enough to not interact with the integrator term, and low enough to keep the DUT stable. Thus,  $C_2$  minimizes noise gain at higher frequencies, which reduces the chance of unwanted feedback effects.

With the overall gain  $G_A G_M$  of either 201 V/V or 1998 V/V, this circuit can measure  $V_{OST}$  values up to either ±12.4 mV or ±1.25 mV. A voltmeter with 1 mV resolution can distinguish steps of either 5  $\mu$ V or 0.5  $\mu$ V, respectively.

The DUT's noise seen at the input to  $G_M$  has a noise power bandwidth (NPBW) set by  $R_{78}$  and  $C_2$  (0.28 kHz). This implies that this noise is dominated by the 1/f noise. The Lowpass Filter ( $f_{BW} \approx 1.6$  Hz) reduces this 1/f noise a little more before it is seen at  $V_M$ . The measured noise, over a 140 second period of time with a typical part, was about 19  $\mu V_{P-P}$  referred to input (RTI). This compares favorably with the MCP651's calibrated  $V_{OS}$  specification (±200  $\mu V$ , maximum at +25°C).

## 1.4.3 DUT Bias Voltage Inputs

Figure 1-3 shows the basic DUT biasing circuitry, except the input pins which have already been discussed ( $V_{CMX} = 0V$ ).



### FIGURE 1-3: DUT Bias Circuitry.

Lab power supplies are connected to V<sub>DDX</sub> and V<sub>SSX</sub>. The resistors R<sub>29</sub>, R<sub>30</sub>, R<sub>37</sub> and R<sub>38</sub>, along with the capacitors C<sub>13</sub>, C<sub>14</sub>, C<sub>21</sub> and C<sub>22</sub>, minimize crosstalk from the other op amps on the board. Since the MCP651's quiescent current is between 3 mA and 9 mA, the actual power supply voltages (V<sub>DDI</sub> and V<sub>SSI</sub>) are different by 30 mV to 90 mV. I<sub>DD</sub> and I<sub>SS</sub> can be calculated as (I<sub>SS</sub> is negative):

#### **EQUATION 1-3:**

$$I_{DD} = \frac{V_{DDX} - V_{DDI}}{10\Omega}$$
$$I_{SS} = \frac{V_{SSX} - V_{SSI}}{10\Omega}$$

The DUT's V<sub>CAL</sub> pin sets its internal common mode voltage (V<sub>CMX</sub> of the MCP651) when it is in calibration mode. Thus, the DUT's offset (V<sub>OS</sub>) is small when V<sub>CMX</sub> (0V on this board) is equal to V<sub>CALX</sub>.

The RCAL potentiometer (POT or R43), with the resistors R<sub>42</sub> and R<sub>43</sub>, sets V<sub>CALX</sub>. The values chosen allow the POT to cover the specified V<sub>CALX</sub> range, and a little more. Connecting a voltmeter to V<sub>CALX</sub> makes it possible to set the POT accurately. Notice that it is also possible to drive V<sub>CALX</sub> with an external voltage source (the wiper should be, but doesn't have to be, at mid-range).

 $V_{OUTX}$  is set, as previously explained, to be equal to  $V_{COX}$  by the integrator in the PI control loop. If  $V_{COX}$  is at or beyond  $V_{SSI}$  or  $V_{DDI}$ , then the loop forces  $V_{OUTX}$  to be railed at the corresponding supply voltage.

The load resistor (R<sub>L</sub> or R<sub>10</sub>) is biased to the externally supplied voltage V<sub>LX</sub>. V<sub>LX</sub> is usually set to mid-supply. The V<sub>LX</sub> connection can be left open, which minimizes the loading on V<sub>OUTX</sub> (about 40 k $\Omega$ ).

### 1.4.4 CAL Input

The DUT's CAL/CS input pin is normally held at  $V_{SSX}$  by resistors  $R_{20}$  and  $R_{21}$ ; this keeps the MCP651 in its normal mode of operation. When  $S_1$  is closed by the user,  $R_{20}$  pulls CAL/CS up to  $V_{DDX}$  (after a time set by  $R_{20}$  and  $C_9$ ), so that the MCP651 enters its low power mode of operation. Releasing  $S_1$  then brings CAL/CS back to  $V_{SSX}$  (after a time set by  $R_{20}$ ,  $R_{21}$  and  $C_9$ ); the time constant ( $R_{20} + R_{21}$ ) $C_9$  is 0.11s, which is slow enough to de-glitch  $S_1$ . Note that the supply voltages need to be constant while the DUT is being put into calibration mode, and during calibration mode (up to 4 ms of time after CAL/CS goes low).



FIGURE 1-4: CAL Switch and De-glitching Circuitry.

### 1.4.5 Bias Inputs for Other Op Amps

The other op amps (U<sub>2</sub>, U<sub>3</sub> and U<sub>4</sub>) are run on dual power supplies centered on ground. The design assumes that these supplies are ±2.5V, for the best performance. These supplies can be set as low as ±0.9V, which will keep the MCP6V01's working, but will reduce the range of possible  $V_{COX}$  and  $V_M$  values.

## 1.4.6 Outputs

The connector V<sub>CALX</sub> outputs the voltage set by the POT RCAL. V<sub>DDI</sub> and V<sub>SSI</sub> are used to measure the actual DUT supply voltages, and to estimate its supply currents I<sub>DD</sub> and I<sub>SS</sub>. V<sub>OUTX</sub> is the DUT's output voltage; it is used only to verify that the circuit is operating correctly. V<sub>M</sub> is the most important output; it is V<sub>OST</sub> multiplied by either 201 V/V or 1998 V/V.



## MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE

## **Chapter 2. Installation and Operation**

## 2.1 INTRODUCTION

This chapter shows how to set up and operate the MCP651 Input Offset Evaluation Board. Items discussed in this chapter include:

- Required Tools
- Configuring the Lab Equipment and PCB
- · Operating Conditions
- Calculating DUT Parameters
- Settling Time, Noise, and Sampling Rate

## 2.2 REQUIRED TOOLS

- (1 or 2) Lab Power Supplies with (two) tracking outputs
  - One for +2.5V, GND -2.5V
  - The other for V\_{DDX}, GND, V\_{SSX} (adjustable up to ±7.0V; optional if V\_{DDX} = 2.5V and V\_{SSX} = -2.5V)
- (0 to 3) independent Lab Power Supplies
  - Drive  $V_{CALX},\,V_{LX}$  and  $V_{COX}$  (any or all of these can be not used, as described in the next section)
  - Adjustable up to ±7.0V
- (1 or 2) Voltmeters
  - Measure V<sub>M</sub>, V<sub>OUTX</sub> (the latter is for troubleshooting only)
  - 1 mV resolution
  - -6V to +6V minimum range
  - Differential measurement (e.g., hand held meter)

## 2.3 CONFIGURING THE LAB EQUIPMENT AND PCB

Lab equipment is connected to this board as shown in Figure 2-1. The (surface mount) test points allow lab equipment to be connected to these boards.



**FIGURE 2-1:** Lab Equipment Connections and Configuration Switches for the MCP651 Input Offset Evaluation Board.

The arrows and numbers in Figure 2-1 signify the following:

- 1. Gain Setting Switch top position (# 1)
  - a) To the right (ON) for low gain ( $G_M = 201 \text{ V/V}$ ).
  - b) To the left for high gain ( $G_M$  = 1998 V/V).
- 2. Voltmeter to measure VM
  - a) Gives amplified offset ( $G_A G_M V_{OST}$ ).
- 3. Power Supply for VCOX
  - a) Can be left open (forces VOUTX = 0V).
  - b) Set between VSSI and VDDI.
- 4. ±2.5V Power Supplies with GND
  - a) Set at +2.5V and -2.5V (for best performance).
- 5. Power Supply for VLX (Load Resistor's bias point)
  - a) Can be left open (fewer lab power supplies;  $R_1 = 40 \text{ k}\Omega$ ).
  - b) Can be shorted to GND with a jumper wire (VLX = 0V and  $R_L = 1 \text{ k}\Omega$ ).
  - c) Can connect to an external lab power supply ( $R_L = 1 k\Omega$ ).

- 6. Voltmeter to measure VOUTX
  - a) Typically not used (mainly used for validating DUT and board).
- 7. POT (RCAL) Thumb-wheel (to adjust VCALX)
  - a) Rotate clockwise (CW) to increase VCALX.
  - b) Rotate counter-clockwise (CCW) to decrease VCALX.
  - c) Usually set at mid-turn.
  - d) Can override with an external power supply at VCALX or a jumper wire (see # 9 below)
- 8. Power Supply for VSSX
  - a) Minimum of about VDDX (DUT's maximum operating supply voltage) (0.12V for the resistors in the supply line).
  - b) Maximum of +0.3V (for V<sub>CMX</sub> at 0.3V below negative rail).
  - c) When VSSX = -2.5V and VDDX = +2.5V, you can connect to the -2.5V supply with a jumper wire (fewer lab power supplies).
- 9. Power Supply for VCALX
  - a) Usually not connected (RCAL sets V<sub>CALX</sub>; fewer lab power supplies).
  - b) Can be shorted to GND with a jumper wire (fewer lab power supplies;  $V_{CALX} = V_{CMX} = 0V$ ).
  - c) Can connect to an external lab power supply (it is best, but not necessary, to set RCAL to mid-supply).
- 10. Power Supply for VDDX
  - a) Minimum of -0.3V (for V<sub>CMX</sub> at 0.3V above positive rail).
  - b) Maximum of about VSSX + (DUT's maximum operating supply voltage) + (0.12V for the resistors in the supply line).
  - c) When VSSX = -2.5V and VDDX = +2.5V, you can connect to the +2.5V supply with a jumper wire (fewer lab power supplies).
- 11. CAL Switch
  - Press to initiate calibration sequence (corrects DUT's V<sub>OST</sub>, with internal common mode voltage set to VCALX).
  - b) There is a delay of about 4 ms for the calibration to complete, plus several tenths of a second for the circuit to settle.
- 12. Voltmeter at VDDI and VDDX (to measure  $I_{DD}$ )
  - a) Measure  $\Delta V = V_{DDX} V_{DDI}$ .
  - b) Calculate  $I_{DD} = \Delta V / (10\Omega)$
- 13. Voltmeter at VSSI and VSSX (to measure  $I_{SS}$ )
  - a) Measure  $\Delta V = V_{SSX} V_{SSI}$ .
  - b) Calculate  $I_{SS} = \Delta V / (10\Omega)$ ; (this is a negative value)

**Note:** For the best accuracy and ease of use, short VCALX to GND, set the other voltages for the desired bias during calibration, then initiate a calibration event in the DUT (push S1). Change the bias point afterwards to see how V<sub>OST</sub> is changed.

## 2.4 OPERATING CONDITIONS

The MCP651 Input Offset Evaluation Board works most effectively at room temperature (near 25°C). Measurements at other temperatures should be done in an oven where the air velocity is minimal. Table 2-1 shows the various DUT voltages (as described in the data sheet), their nominal values and ranges, and how to convert to the voltages needed on the MCP651 Input Offset Evaluation Board.

	Single Supply Vo			
Data Sheet Symbol	Nominal	Range	Conversion Equations (V)	
V <sub>DD</sub>	2.5 or 5.5	2.5 to 5.5	$V_{DDX} \leftarrow V_{DD} - V_{CM}$	
V <sub>SS</sub>	0	0	$V_{SSX} \leftarrow V_{SS} - V_{CM}$	
V <sub>CM</sub>	V <sub>DD</sub> /3	V <sub>SS</sub> – 0.3 to V <sub>DD</sub> – 1.3 (Note 1)	$0 \qquad \leftarrow V_{CM} - V_{CM}$	
V <sub>OUT</sub> (Note 2)	V <sub>DD</sub> /2	$V_{SS}$ + 0.2 to $V_{DD}$ – 0.2	$V_{OUTX} \leftarrow V_{OUT} - V_{CM}$	
VL	V <sub>DD</sub> /2	$V_{SS}$ to $V_{DD}$	$V_{LX} \leftarrow V_L - V_{CM}$	
V <sub>CAL</sub>	V <sub>DD</sub> /3 (Note 3)	$V_{SS}$ + 0.1 to $V_{DD}$ – 1.4	$V_{CALX} \leftarrow V_{CAL} - V_{CM}$	
CAL/CS	V <sub>SS</sub>	$V_{SS}$ to $V_{DD}$	(Note 4)	

TABLE 2-1: CONVERTING VOLTAGES FOR THE BOARD

**Note 1:** At  $T_A = +25^{\circ}C$ . See the data sheet for changes in  $V_{CM}$  range vs.  $T_A$ .

- 2: Set the desired V<sub>OUT</sub> voltage at the V<sub>COX</sub> input; the integrator then forces V<sub>OUT</sub> to be the same voltage.
- **3:** When the V<sub>CAL</sub> pin left open. However, this board always has the POT (R43) connected, so V<sub>CALX</sub> is never truly open.
- **4:** The circuit forces CAL/CS to stay within its range (as long as the supply voltages are constant when the CAL switch is activated). Normally, the part is on.
- **5**: These numbers are for the MCP651 op amp.

Once the MCP651 Input Offset Evaluation Board is powered up, the switches can be set for the desired operation. S1 (a normally off push-button switch) starts a calibration event (CAL), internal to the DUT, when pushed. S2 (top position) sets the gain of the amplifier ( $G_M$ ) either high or low. See Table 2-2 for details.

TABLE 2-2: SWITCH OPERATION

Switch	Input	Result	
S1	No Input	Normal Operation	
	Pushed	Calibration event started in DUT	
S2	Top Switch to the left	High Gain (1998 V/V)	
	Top Switch to the right	Low Gain (201 V/V)	
	(Bottom Switch)	(Don't Care)	

The gain is usually set low. It can be set high just after a calibration event, before changing the DUT's bias point, to obtain more accurate results for the calibrated offset voltage.

The POT ( $R_{CAL}$  or  $R_{43}$ ) adjusts  $V_{CALX}$ . This voltage is where the DUT's common mode input voltage set during a calibration event (initiated by pushing S1). Adjusting this POT does not have an effect on the circuit's behavior until the CAL switch (S1) is pushed.

### 2.5 CONVERTING TO OTHER PARAMETERS

#### 2.5.1 Calculating DUT Parameters

The DUT's total input offset voltage ( $V_{OST}$ ) can be calculated from a measurement as shown in Equation 2-1.

#### EQUATION 2-1:

 $V_{OST} = V_M / (G_A G_M)$ 

Changing the DUT's bias voltages or ambient temperature changes  $V_{OST}$ . Microchip's application note AN1177 discusses in detail how these changes in  $V_{OST}$  are related to specifications found in our data sheets. The following list summarizes the results:

- Specified Input Offset Voltage:
  - V<sub>OS</sub> = Input offset at the specified bias point
- DC Common Mode Rejection Ratio:
  - CMRR =  $\Delta V_{CM} / \Delta V_{OS}$
- DC Power Supply Rejection Ratio:
  - PSRR =  $(\Delta V_{DD} \Delta V_{SS})/\Delta V_{OS}$
- DC Open-loop Gain:
  - $A_{OL} = \Delta V_{OUT} / \Delta V_{OS}$
- Input Offset Drift over Temperature:
  - $\Delta V_{OS} / \Delta T_A$

**Note:** The data sheet Input Offset Voltage ( $V_{OS}$ ) specification applies to one bias point and temperature only. The total input offset voltage ( $V_{OST}$ ) includes  $V_{OS}$  and changes in input offset as bias voltages and temperature change.

Example 2-1 gives an example of how  $V_{OST}$  changes with the common mode input voltage ( $V_{CM}$ ).

#### EXAMPLE 2-1: COMMON MODE CHANGE EXAMPLE

Given:  $V_{OST} = 0.5 \text{ mV}, \quad V_{CM} = 0V$   $V_{OST} = 1.0 \text{ mV}, \quad V_{CM} = 5V$ Then:  $\Delta V_{OST} = 0.5 \text{ mV}$   $\Delta V_{CM} = 5.0V$ CMRR = 5.0V / 0.5 mV = 10 V/mV = 80 dB

### 2.5.2 Application

Table 2-3 shows one possible measurement matrix that will allow the user to estimate key parameters for the DUT. Obviously, other values of  $V_{DD}$  and  $V_{CAL}$  could be selected.

	Operating Inputs		Operating Inputs Measurement (Note 1)		Measurement (Note 1)		
T <sub>A</sub> (°C)	V <sub>DD</sub> (V)	V <sub>OUT</sub> (V)	V <sub>CM</sub> (V)	G <sub>M</sub> (V/V)	Symbol	Comments	
+25	5.5	2.75	1.83	40	V <sub>M1</sub>	V <sub>OS</sub> and PSRR	
			-0.30	4	V <sub>M2</sub>	CMRR	
			4.20		V <sub>M3</sub>	CMRR	
		0.20	1.83		V <sub>M4</sub>	A <sub>OL</sub>	
		5.30			V <sub>M5</sub>	A <sub>OL</sub>	
	2.5	1.25	0.83		V <sub>M6</sub>	V <sub>OS</sub> and PSRR	
			-0.30		V <sub>M7</sub>	CMRR	
			1.20		V <sub>M8</sub>	CMRR	
		0.20	0.83		V <sub>M9</sub>	A <sub>OL</sub>	
		2.30			V <sub>M10</sub>	A <sub>OL</sub>	
-40	5.5	2.75	1.83		V <sub>M11</sub>	$V_{OS}$ at temperature and $\Delta V_{OS}/\Delta T_A$	
+85					V <sub>M12</sub>		
+125					V <sub>M13</sub>		

TABLE 2-3: MEASUREMENT MATRIX

**Note 1:** Before making these measurements, set up the DUT to the bias point described for  $V_{M1}$ . Short  $V_{CALX}$  to GND. Then start a calibration (CAL) event using S1. Measure  $V_{M1}$ , then alter the operating conditions for each succeeding measurement; do not initiate another calibration event until all measurements are done.

Based on these measurements, we can make the following estimates, where the  $V_{OST\_k}$  values are calculated from the measured  $V_{Mk}$  values (see Equation 2-1):

Operating Inputs		Estimates	
V <sub>DD</sub> (V)	T <sub>A</sub> (°C)	Equations Units	
1.8 and 5.5	+25	$1/PSRR = (V_{OST_1} - V_{OST_6}) / (3.0V)$	μV/V
5.5	-40	V <sub>OS</sub> = V <sub>OST_11</sub>	μV
	+25	V <sub>OS</sub> = V <sub>OST_1</sub>	μV
	+85	V <sub>OS</sub> = V <sub>OST_12</sub>	μV
	+125	V <sub>OS</sub> = V <sub>OST_13</sub>	μV
	-40 to +125	$\Delta V_{OS} / \Delta T_{A} = (V_{OST_{13}} - V_{OST_{11}}) / (165^{\circ}C)$	μV/°C
	+25	1/CMRR = (V <sub>OST_3</sub> – V <sub>OST_2</sub> ) / (4.5V)	μV/V
		$1/A_{OL} = (V_{OST_5} - V_{OST_4}) / (5.1V)$	μV/V
1.8	+25	V <sub>OS</sub> = V <sub>OST_6</sub>	μV
		$1/CMRR = (V_{OST_8} - V_{OST_7}) / (1.5V)$	μV/V
		$1/A_{OL} = (V_{OST_{10}} - V_{OST_{9}}) / (2.1V)$	μV/V

Obviously, other values of  $T_A$ ,  $V_{DD}$ , ... can be used instead, with the proper adjustments to these equations.

### 2.6 SETTLING TIME, NOISE AND SAMPLING RATE

The bandwidth seen by the signal (DUT's  $V_{OST}$  and noise voltage), between the DUT's input and VM, is set mainly by the lowpass filter at the VM test point (TP5); this bandwidth is about 1.6 Hz. This bandwidth sets the settling time seen at VM (after the DUT's bias point has been changed) to about 0.6 seconds.

The noise seen in the measurements is a result of DUT's input noise voltage passed through the same 1.6 Hz lowpass filter. The MCP651's 1/f noise dominates at such low frequencies, so  $V_{OST}$  will appear to wander over time. The standard deviation of this 1/f wander can be estimated to be roughly:

- + 5  $\mu V_{P\text{-}P}$  for a time period of 1 second
- + 34  $\mu V_{P-P}$  for a time period of 10 years

Averaging several measurements together will help reduce the noise over a short period of time. It must be understood, however, that the 1/f noise will make  $V_{OST}$  appear to change over long periods of time.

There is a practical limit on increasing the sample rate; the noise does not improve significantly after a certain point. The analog lowpass pole at 1.6 Hz causes closely spaced samples to be correlated. To avoid the overhead caused by sampling too fast, keep the sampling period near or above the pole's time constant (0.10s); this gives a minimum sample rate of 10 samples per second.

**Note:** Sampling much faster than 10 SPS will not improve the averaged noise significantly.

NOTES:



## MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE

## **Chapter 3. Possible Modifications**

## 3.1 INTRODUCTION

This chapter shows how to modify the MCP651 Input Offset Evaluation Board to measure other single op amps from Microchip Technology Inc. Items discussed in this chapter include:

- · Range of Parts Supported by the MCP651 Input Offset Evaluation Board
- · Changes to Accommodate Other DUTs

### 3.2 RANGE OF PARTS SUPPORTED BY MCP651 INPUT OFFSET EVALUATION BOARD

Only op amps that fall within a certain performance range are supported by the MCP651 Input Offset Evaluation Board.

### 3.2.1 Input Offset Voltage

In order to keep op amps U3 and U4 operating normally, the DUT's  $V_{OS}$  must be:

#### EQUATION 3-1:

 $V_{OS} < \pm 12.4 \text{ mV}$ , Low Gain  $V_{OS} < \pm 1.25 \text{ mV}$ , High Gain

Where:

Low Gain = 201 V/V High Gain = 1998 V/V

More accurate op amps need higher gain for good resolution. Table 3-1 shows what  $V_{OS}$  specs can be supported for different voltmeter resolutions and amplifier gains.

#### TABLE 3-1: LOWER LIMIT ON V<sub>OS</sub> RANGE (NOTE 1)

Voltmeter Resolution (mV)	G <sub>A</sub> G <sub>M</sub> (V/V)	<i>max</i> (V <sub>OS</sub> ) ≥ (±μV)
1 mV	201 (low gain)	500
	1998 (high gain)	50
0.1 mV	201 (low gain)	50
	1998 (high gain)	5 (Note 2)

**Note 1:** These results assume a minimum measurement resolution of 1% of the  $V_{OS}$  range.

2: The DUT needs to be soldered to the PCB when the maximum  $V_{OST}$  is less than  $\pm 50 \ \mu$ V, or so. Inserting a PDIP-8 part into a 8-pin socket creates a contact potential (error) of the order of  $\pm 1 \ \mu$ V. Also, 1/f noise needs to be low.

### 3.2.2 Output Headroom

The DUT's output headroom needs to be close enough to 0V to not overdrive U2 or U3. The maximum DUT  $V_{OH}$  and  $V_{OL}$  values supported (relative to  $V_{CM}$ ) are:

#### **EQUATION 3-2:**

 $V_{OH} - V_{CM} \le 7.5 V$  $V_{CM} - V_{OL} \le 7.5 V$ 

Rail-to-rail output op amps, on a single supply voltage, must be less than 7.5V.

#### 3.2.3 Gain Bandwidth Product

There is a minimum Gain Bandwidth Product (GBWP) to keep the feedback loop stable, and a maximum GBWP to avoid crosstalk and other issues.

#### **EQUATION 3-3:**

 $500 \ kHz \leq GBWP \leq 100 \ MHz$ 

## 3.3 CHANGES TO ACCOMMODATE OTHER DUTS

This section focuses on methods to connect to other DUTs; the circuit's design is not changed. Parts information can be found in **Appendix B. "Bill Of Materials (BOM)"**.

#### 3.3.1 Pinout

Figure 3-1 shows the MCP651 op amp's pinout. This is the standard 8-lead pinout, except for pins 5 and 8 ( $V_{CAL}$  and CAL/CS). The MCP651 Input Offset Evaluation Board is designed to take advantage of these input pins, but they are not necessary to this board's operation.



FIGURE 3-1: MCP651 Pinout.

Op Amps with No Connection (NC) at pins 1, 5 and 8 will operate properly on the MCP651 Input Offset Evaluation Board. Other op amps may need to use an adaptor board; see **Section 3.3.5 "Other Single Op Amps"**.

### 3.3.2 Removing the DUT

Since these boards come with the DUT (in SOIC-8) soldered on, it is necessary to de-solder them. Figure 3-2 shows the location of the DUT for either a SOIC-8 or a PDIP-8 package. A good de-soldering station makes this work much easier to do.



FIGURE 3-2: DUT's Location on the PCB.

### 3.3.3 Single Op Amps in SOIC-8 Package

Solder onto the SOIC-8 pad shown in Figure 3-2. Pin 1 is on the top left (next to the U1 label). To avoid soldering and de-soldering many times, for slower parts, it may be better to use the option discussed in **Section 3.3.5 "Other Single Op Amps"**.

### 3.3.4 Single Op Amps in PDIP-8 Package

Remove the original SOIC-8 packaged part. Solder a DIP-8 IC Socket in the PDIP-8 location shown on Figure 3-2; this makes it easy to change PDIP-8 parts. It also is helpful for parts for other package and pinout options; see **Section 3.3.5 "Other Single Op Amps"**. Figure 3-3 shows this board after the DIP-8 IC socket has been installed.





The socket may not work well in two cases (solder directly to the PCB instead):

- Very fast op amps (i.e., GBWP > 100 MHz)
- Very accurate op amps (i.e., V<sub>OST</sub> < ±50 μV)</li>

## 3.3.5 Other Single Op Amps

With a DIP-8 IC Socket on the evaluation board (see **Section 3.3.4 "Single Op Amps in PDIP-8 Package"**), it is relatively easy to adapt the MCP651 Input Offset Evaluation Board to many other op amps. An adaptor board is stacked on top using headers that solder to the adaptor board, using PDIP-8 through holes, and are inserted into the DIP-8 socket on the evaluation board. The adaptor board can accommodate:

- Different packages
- Different pinout options (can be dealt with on the adaptor board)
- · Parts with multiple op amps

The adaptor boards approach may not work well in two cases:

- Fast op amps (i.e., GBWP > 10 MHz); adding bypass capacitors to the adaptor board may help
- Accurate op amps (i.e., V<sub>OST</sub> < ±50 μV)</li>

Figure 3-4 shows a SOIC-8 op amp soldered onto the 8-Pin SOIC/MSOP/TSSOP/DIP Evaluation Board available from Microchip Technology Inc. The two interconnect strips on the bottom are soldered into the through holes for the DIP-8 socket. Figure 3-5 shows this board plugged into the MCP651 Input Offset Evaluation Board.

**Note 1:** Build the adaptor board in the following sequence. Insert the interconnect headers into the DIP-8 socket on the MCP651 Input Offset Evaluation Board. Place the SOIC8EV board on the top of the interconnect headers, while maintaining the correct pin orientation. Solder the headers to the top board. Clip the pins flush with the top surface of the SOIC8EV board, then solder the (SOIC-8) op amp on the top.



**2:** See Table B-4 for part numbers of this board and its components.

FIGURE 3-4:Op Amp in SOIC-8 Package and Connector Headers Soldered toAdaptor PCB.



**FIGURE 3-5:** Adaptor Board Connected to the MCP651 Input Offset Evaluation Board.

NOTES:



## MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE

## **Appendix A. Schematics and Layouts**

## A.1 INTRODUCTION

This appendix contains the schematics and layouts for the MCP651 Input Offset Evaluation Board.

### A.2 SCHEMATIC AND LAYOUTS

See A.3 "Board – Schematic" for the circuit diagram. U1 is the DUT (MCP651). U2 buffers the attenuated and filtered control voltage VCOX. U3 is the differential integrator. U4 is the amplifier that gives the final gain to the DUT's input offset voltage ( $V_{OST}$ ). Switch S1 gives the user a means of starting an auto-calibration cycle in the DUT. Switch S2 makes it so the amplifier (U4) can have two different gains, providing a tradeoff between accuracy and range.

**A.4 "Board – Combination of the Top Silk-Screen, Top Solder Mask and Top Metal Layers**" through **A.7 "Board – Bottom Metal Layer**" show the PCB layout plots. This PCB has two metal layers: signal and power traces on top and ground plane on bottom. Groups of critical resistors have been arranged so that their thermoelectric voltages cancel (assuming constant temperature gradient); these groups are:

- R<sub>1</sub> through R<sub>4</sub>
- R<sub>5</sub> and R<sub>6</sub>
- R<sub>7</sub> and R<sub>8</sub>
- R<sub>21</sub> through R<sub>23</sub>
- R<sub>24</sub> and R<sub>25</sub>

The Gerber files for this board are available on the Microchip website (www.microchip.com) and are contained in the zip file "00258R2\_Gerbers.zip".

## MCP651 Input Offset Evaluation Board User's Guide

## A.3 BOARD – SCHEMATIC



A.4 BOARD – COMBINATION OF THE TOP SILK-SCREEN, TOP SOLDER MASK AND TOP METAL LAYERS



## MCP651 Input Offset Evaluation Board User's Guide

## A.5 BOARD – TOP SILK-SCREEN





## A.6 BOARD – TOP SOLDER MASK AND TOP METAL LAYER

MCP651 Input Offset Evaluation Board User's Guide

A.7 BOARD – BOTTOM METAL LAYER





## MCP651 INPUT OFFSET EVALUATION BOARD USER'S GUIDE

## **Appendix B. Bill Of Materials (BOM)**

## B.1 MCP651 INPUT OFFSET EVALUATION BOARD BOM

The BOM in Table B-1 shows all of the components assembled on the PCB. Table B-2 shows alternate components that can be placed on this PCB (after modification). Table B-3 shows components that are not populated.

#### TABLE B-1: BILL OF MATERIALS FOR ASSEMBLED PCB

Qty	Reference Designator	Description	Manufacturer	Part Number
1	C8	1.0 nF, 0603 SMD, X7R, 16V, 10%	Panasonic <sup>®</sup> -ECG	ECJ-1VB1H102K
1	C2	22 nF, 0603 SMD, X7R, 16V, 10%	Panasonic-ECG	ECJ-1VB1C223K
1	C10	33 nF, 0603 SMD, X7R, 16V, 10%	Panasonic-ECG	ECJ-1VB1C333K
11	C3, C11, C13 – C20, C25	100 nF, 0603 SMD, X7R, 16V, 10%	Panasonic-ECG	ECJ-1VB1C104K
2	C6, C7	150 nF, 1206 SMD, X7R, 50V, 10%	Panasonic-ECG	ECJ-3VB1C154K
4	C4, C5, C9, C12	1.0 μF, 1206 SMD, X7R, 16V, 10%	Panasonic-ECG	ECJ-3YB1C105K
4	C21 – C24	10 μF, 1206 SMD, X7R, 16V, 10%	Panasonic-ECG	ECJ-3YX1C106K
1	PCB	MCP651 Input Offset Evaluation Board, 2-layer PCB (3.00 in × 2.50 in)	Microchip Technology Inc.	102-00258
2	R2, R3	200Ω, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-201-B-T5
1	R23	5.10 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-512-B-T5
1	R4	10.0 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-103-B-T5
1	R24	15.0 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-153-B-T5
1	R26	86.6 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-8662-B-T5
1	R25	93.1 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-9312-B-T5
2	R12, R14	150 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-154-B-T5
2	R11, R13	332 kΩ, 0603 SMD, 0.1%, 25 ppm/°C, 1/10W	Susumu Co. Ltd.	RG1608P-3323-B-T5
2	R37, R38	4.99Ω, 0603 SMD, 1%, 1/10W	Yageo	RC0603FR-074R99L
1	R10	1.00 kΩ, 0603 SMD, 1%, 1/10W	Panasonic-ECG	ERJ-3EKF1001V
2	R5, R6	4.02 kΩ, 0603 SMD, 1%, 1/10W	Panasonic-ECG	ERJ-3EKF4021V
1	R22	4.99 kΩ, 0603 SMD, 1%, 1/10W	Panasonic-ECG	ERJ-3EKF4991V
2	R7, R8	20.0 kΩ, 0603 SMD, 1%, 1/10W	Panasonic-ECG	ERJ-3EKF2002V
1	R17	102 kΩ, 0603 SMD, 1%, 1/10W	Panasonic-ECG	ERJ-3EKF1023V
4	R31, R35, R36, R40	10Ω, 0603 SMD, 5%, 1/10W	Panasonic-ECG	ERJ-3GEYJ100V
1	R27	100Ω, 0603 SMD, 5%, 1/10W	Panasonic-ECG	ERJ-3GEYJ101V
2	R16, R18	3.3 kΩ, 0603 SMD, 5%, 1/10W	Panasonic-ECG	ERJ-3GEYJ332V
4	R1, R9, R19, R21	10 kΩ, 0603 SMD, 5%, 1/10W	Panasonic-ECG	ERJ-3GEYJ103V
3	R15, R20, R28	100 kΩ, 0603 SMD, 5%, 1/10W	Panasonic-ECG	ERJ-3GEYJ104V
2	R29, R30	4.99Ω, 1206 SMD, 1%, 1/4W	Yageo	RC1206FR-074R99L

**Note 1:** The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

Qty	Reference Designator	Description	Manufacturer	Part Number
5	R32 – R34, R39, R41	10Ω, 1206 SMD, 5%, 1/4W	Panasonic-ECG	ERJ-8GEYJ100V
1	R42	150Ω, 1206 SMD, 5%, 1/4W	Panasonic-ECG	ERJ-8GEYJ151V
1	R44	2.2 kΩ, 1206 SMD, 5%, 1/4W	Panasonic-ECG	ERJ-8GEYJ222V
1	R43	10 k $\Omega$ POT, SMD, 20%, 1 Turn Thumbwheel	Bournes Inc.	3352T-1-103LF
1	S1	SPST-NO, SMD, Switch, Push Button, 1 Pos.	Panasonic-ECG	EVQ-P2R02M
1	S2	SMD, Switch, DIP, 2 Pos.	Grayhill Inc.	90HBW02PT
15	TP1 – TP15	SMD, Test Point	Keystone Electronics <sup>®</sup>	5016
1	U1	SOIC-8, Single Op Amp	Microchip	MCP651-E/SN
3	U2 – U4	MCP6V01, SOIC-8, Single Op Amp	Technology Inc.	MCP6V01-E/SN
4	(for PCB mounting)	Hemispherical Bumpon Standoff, 0.44 in × 0.20 in	3М	SJ-5003 (BLACK)

**Note 1:** The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

TABLE B-2:	BILL OF MATERIALS FOR ALTERNATE COMPONENTS
------------	--

Qty	Reference Designator	Description	Manufacturer	Part Number
0	U1	PDIP-8, Single Op Amp	Microchip Technology Inc.	MCP6XXX (Note 1)
0	U1	DIP-8 IC Socket	Tyco Electronics	2-641260-1
0	(for PCB mounting)	Stand-off, Hex, 0.500", 4 × 40 Thread, Nylon, 0.285" max. O.D.	Keystone Electronics	1902C
0	(for PCB mounting)	Machine Screw, Phillips, 4 × 40 Thread, 1/4" long, Nylon	Building Fasteners	NY PMS 440 0025 PH

**Note 1:** The MCP6XXX represents any Microchip single op amp, with standard pinout, that fits the given design.

2: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

TABLE B-3: BILL OF MATERIALS FOR NOT POPULATED COMPONENTS

Qty	Reference Designator	Description	Manufacturer	Part Number
0	C1	Unknown Value, 0603 SMD, X7R, 16V, 10%	Panasonic <sup>®</sup> -ECG	—

**Note 1:** The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

## **B.2 ADAPTOR BOARD BOM**

The BOM in Table B-4 shows the components needed to build the adaptor board for alternate DUT's (see Figure 3-4).

Qty	Reference Designator	Description	Manufacturer	Part Number
1	_	8-Pin SOIC/MSOP/TSSOP/DIP Evaluation Board	Microchip Technology Inc.	SOIC8EV
2	_	Board-to-Board Connector, Low Profile Header, 4 Positions, 0.100 in, Gold Plated	Samtec Inc.	BBL-104-G-F
2	_	100 nF, 0603 SMD, X7R, 16V, 10%	Panasonic <sup>®</sup> -ECG	ECJ-1VB1C104K
1		Single Op Amp in Standard 8-pin pinout	Microchip Technology Inc.	MCP6XXX

**Note 1:** The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.



## WORLDWIDE SALES AND SERVICE

#### AMERICAS

Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: http://support.microchip.com Web Address: www.microchip.com

Atlanta Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

Boston Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL Tel: 630-285-0071 Fax: 630-285-0075

Cleveland Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Kokomo Kokomo, IN Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto Mississauga, Ontario, Canada Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

Asia Pacific Office Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431 Australia - Sydney

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

**China - Beijing** Tel: 86-10-8528-2100 Fax: 86-10-8528-2104

**China - Chengdu** Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

**China - Hong Kong SAR** Tel: 852-2401-1200 Fax: 852-2401-3431

China - Nanjing Tel: 86-25-8473-2460

Fax: 86-25-8473-2470 China - Qingdao

Tel: 86-532-8502-7355 Fax: 86-532-8502-7205 China - Shanghai

Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

**China - Shenyang** Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

**China - Shenzhen** Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

**China - Wuhan** Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

**China - Xiamen** Tel: 86-592-2388138 Fax: 86-592-2388130

**China - Xian** Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

**China - Zhuhai** Tel: 86-756-3210040 Fax: 86-756-3210049

#### ASIA/PACIFIC

India - Bangalore Tel: 91-80-3090-4444 Fax: 91-80-3090-4080

India - New Delhi Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

**Japan - Yokohama** Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Daegu Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

**Malaysia - Penang** Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu Tel: 886-3-6578-300 Fax: 886-3-6578-370

Taiwan - Kaohsiung Tel: 886-7-536-4818 Fax: 886-7-536-4803

Taiwan - Taipei Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

**Thailand - Bangkok** Tel: 66-2-694-1351 Fax: 66-2-694-1350

#### EUROPE

Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

**Germany - Munich** Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340

**Spain - Madrid** Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820



Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию.

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России, а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научноисследовательскими институтами России.

С нами вы становитесь еще успешнее!

#### Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург, Промышленная ул, дом № 19, литера Н, помещение 100-Н Офис 331