

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 563

SINGLE AND DUAL MARGINING CONTROLLER

LTC2920-1CS5
LTC2920-2CMS8

DESCRIPTION

Demonstration circuit 563 contains two separate circuits: a (single channel) LTC2920-1 and a (dual channel) LTC2920-2 Power Supply Margining Controllers. This board is meant to be connected to up to three power supplies and demonstrates the voltage margining capabilities of the LTC2920. The board is scribed for easy separation of the two circuits if desired. Each circuit contains a Margining Controller, bypass

capacitor, and pads for external connections. There are also component locations for adding 0805 resistors. **These resistors are specific to each application and must be installed to demonstrate Voltage Margining.**

Design files for this circuit board are available. Call the LTC factory.

QUICK START PROCEDURE

Referring to Figure 1, the Vcc1 and Gnd1 pins provide the power and ground connections for the LTC2920-1 (single). The Vcc2 and Gnd2 pins provide the power and ground connections for the LTC2920-2 (dual). The Vcc voltage can generally be varied between 2.2V and 6.0V. Vcc must be at least 0.6 volts higher than the voltage at the Im pin. See the LTC2920 Data Sheet for other design considerations on minimum Vcc voltage and Vcc filtering. Be sure to connect the ground pin(s) to the same ground as the power supply(s) being margined.

For margining power supplies with external feedback resistors, the Im pins should be connected to the power supply feedback node. For margining power supplies using trim pins, the Im pin should be connected to the power supply trim pin.

The Imargin current sourced or sunk from each Im pin is individually programmed by its respective on board Rset resistor. For the LTC2920-1 circuit, there are two possible locations for the Rset resistor. Placing the Rset resistor in the 'RLOW' position will program the Imargin current at $1V / Rset$. Placing the Rset resistor in the 'RHI' position will program the Imargin current at $30 * 1V / Rset$. See the LTC2920 Data Sheet for the specification limits of the high and low current ranges. On the LTC2920-2 circuit, there

are two positions for each of the two Rset resistors. The 'R1L' and 'R2L' positions are similar to the 'RLOW' position described above. The 'R1H' and 'R2H' positions are similar to the 'RHI' position described above.

The In pins can be connected to a system controller that has a 3-state output, or manually connected as shown. When using a 3-state output to control the In pin, placing the (3-state) output in the high-Z state will 'float' the In pin, and cause the controlled Im pin to be in a high impedance state. Raising an In pin above 2.0 Volts will cause its respective Im pin to sink current. Lowering an In pin below 0.6 Volts will cause its respective Im pin to source current. See the LTC2920 Data Sheet for details. The In pins may also be controlled manually by connecting them to Vcc, ground, or left floating.

After calculating and inserting the Rset resistor(s) as described above, place the DC563 board as close as possible to the power supply(ies) being margined. The ground, Vcc, and Im pins should be connected with the shortest practical wires.

With power applied, the power supply output(s) should be at their nominal values with the In pin(s)

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 563

SINGLE AND DUAL MARGINING CONTROLLER

floating. Raising the In pin(s) above 2.0 V will cause the power supply output voltage to increase by the desired margin voltage. Lowering the In pin(s) below 0.6 V will cause the power supply output voltage to decrease by the desired margin voltage. **When connected to 'trim' pins on DC to DC modules, the polarity of the voltage margining may be inverted.**

If the LTC2920 Vcc pin is connected to power supplies that are compensated to be only ‘marginally stable,’ oscillations may be observed. If oscillations are observed while margining a power supply, connect the Vcc pin to the power supply using an axial lead resistor instead of a wire. See the LTC2920 Data Sheet for calculating the value of this resistor.





Figure 1. Proper Measurement Equipment Setup

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 563

SINGLE AND DUAL MARGINING CONTROLLER



CONTRACT NO.
APPROVALS
DRAWN: KIM T.
CHECKED:
APPROVED:
ENGINEER: JEFF H.
DESIGNER:

1630 McCarthy Blvd.
Milpitas, CA 95035
Phone: (408)432-1900
Fax: (408)434-0507
LTC Confidential-For Customer Use Only



TITLE:

SINGLE AND DUAL MARGINING CONTROLLER

SIZE DWG NO. REV
A DC563A-A * LTC2920-1CS5
DC563A-B * LTC2920-2CMS8

DATE: Friday, August 15, 2003 SHEET 1 OF 1

NOTES: UNLESS OTHERWISE SPECIFIED

1. ALL RESISTORS ARE OPTIONAL, 0805.
2. ALL CAPACITORS ARE 0805.



**Стандарт
Электрон
Связь**

Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию .

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России , а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научно-исследовательскими институтами России.

С нами вы становитесь еще успешнее!

Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург,
Промышленная ул, дом № 19, литера Н,
помещение 100-Н Офис 331