

# Quickstart Guide Using the BHI160 / BHI160B shuttle board

App	lication	Note
-----	----------	------

Document revision

Document release date 04 January 2017

Document number BST-BHy1-AN002-01

1.1

Technical reference code(s)

Notes

0 273 141 230 0 273 141 309

Data in this document are subject to change without notice. Product photos and pictures are for illustration purposes only and may differ from the real product's appearance.



#### **Index of Contents**

1	GENERAL DESCRIPTION	3
2	PC CONNECTION	3
3	DOWNLOADING THE RAM FIRMWARE IMAGE	5
4	CONFIGURING THE SENSOR	9
5	STREAMING THE DATA	12
6	ACTIVATING MORE THAN ONE VIRTUAL SENSOR	13

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



### **1** General description

This guide will guide you step by step and explain how to connect the BHI160 shuttleboard to a Windows computer using the Application board 2.0, configuring it and streaming data.

## 2 PC connection

Make sure that the rightmost 2 DIP switches are in the "ON" position.



Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017



Open the "Development Desktop 2.0" windows application. You will be prompted with the following dialog:

Communication Interface	And A STATE
Communication Channel	USB
Communication Status	•
Connect	Application exit UI Ver: 3.2.4.0
No response from the board.	

UI version should be greater or equal than 3.1.2.1

Connect the Application board 2.0 to one of the USB ports and turn is on via the sliding switch. Make sure it is connected to the computer in the device manager. It should show up under the "BST Board" category.



Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017



#### **3** Downloading the RAM firmware image

Click connect. Development Desktop will start, recognize the BHI160 and you will be prompted to download the RAM patch.

🐻 Download RAM	firmware image for BHY			<b>x</b>
Hardware version	on	Devision ID :	0-0001	
Product ID :	0X0083	Revision ID :	00001	<u>\</u>
-Firmware version	on 0-0440	Databasis		
ROM version :	0x2112	RAM version :	0x0000	
Select .fw file :				
Downloa	d			

Click on the "..." and select the "Bosch\_PCB\_7183\_dixx\_BMI160\_BMM150-7183\_dixx.x.x.xxxx" located in the "C:\Program Files\Bosch Sensortec\Development Desktop 2.0\Firmware\BHI" folder on your computer.

🐷 Download RAM firmware image for BHY				
Hardware versi Product ID :	on 0x0083	Revision ID :	0x0001	
Firmware version :	on 0x2112	RAM Version :	0x2812	
Select .fw file :	PCB_7183_di01_BI	MI160_BMM150-7183_di	01.2.1.10258.fw	
Downloa	d 📕			

Next, click on download. You should see the text "BHY firmware is updated ...".

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017



Close this dialog.

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017

Bosch Sensortec

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



Then, Click on the refresh button on the bottom right corner.

	- 0 ×
6	BOSCH Invented for life
💷 🗆 🗶 General Settings	_ ×
System Virtual Sensor	
Plot1 Accelerometer(Non-Wakeup)	-
Plot2 Accelerometer(Non-Wakeup)	-
Plot3 Accelerometer(Non-Wakeup)	-
Active Virtual Sensors No Active sensor found	-
BHI Working Status	
FIFO Wakeup	
FIEO Non Wakeup	bytes
Watermark 0 V Size	bytes
Application processor suspended	
BSX Library	
ODR	
Physical sensor working status	
Accelerometer Magnetometer Gyroscope	
Sampling Rate	
Range	
Power Mode	
Interrupt Enable	
Error Indicator	
Orientation	
Roll Degree Pitch	Degree
Heading Degree	
Calibration status	
Accelerometer	all
Gyroscope	
Cirsable interrupt Reset System Refr	esn
Const	ection status

This will poll the sensor to refresh all the statuses.

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



You should then see that all the sensors are in the "Power Down" state, with a sampling rate of 0Hz. This means that everythin is working normally.

Accelerometer	Mag	gnetometer	Gyroscop	e
Sampling Ra	te	0 Hz		]
Range		0 g		]
Power Mode		Power Dow	'n	]
Interrupt Enal	ble	•		

Accelerometer Ma	gnetometer Gyrosco	pe
Sampling Rate	0 Hz	
Range	2000 µT	
Power Mode	Power Down	
Interrupt Enable	0	

Accelerometer M	lagnetometer G	yroscope
Sampling Rate	0 Hz	
Range	0 °/s	
Power Mode	Power Down	
Interrupt Enable	•	

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017



# 4 Configuring the sensor

Next step is to enable a virtual sensor. Click on the "Virtual Sensor" tab on the top right.

		- 0 <b>X</b>
	6	BOSCH Invented for life
General Settings		_ X
System Virtual Senso	r	
Plot1	Accelerometer(Non-Wakeup)	•
Plot2	Accelerometer(Non-Wakeup)	•
Plot3	Accelerometer(Non-Wakeup)	•
Active Virtual Sensors	No Active sensor found	•
BHI Working Status		
FIFO Wakeup		
Watermark	0 🔷 Size	bytes
FIFO No. INC.		

Click on the "Write Info" tab

General Settings		_ X
System Virtual Sensor		
Virtual Sensor	Accelerometer(Non-Wakeup)	<b>•</b>
Read Info Write Info	0	
SensorType	1	
DriverID	48	
DriverVersion	1	
Power	1	
Max Range	16	
Resolution	16	
Max Rate	200	
FIFO Reserved	0	
FIFO Max	782	
Event size	8	
Min Rate	1	
Read		

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017

Bosch Sensortec



From the drop-down list, select the sensor "Game Rotation Vector(Non-Wakeup)". Set the sample rate to 200Hz, and the latency to 250ms. This means that the BHI160 will buffer the data for 250ms before sending it to the Host. Then click Write.

General Settings
System Virtual Sensor
Virtual Sensor Game Rotation Vector(Non-Wakeup)
Read Info Write Info
Sample Rate 200 Hz (Fastest Mode) - Hz
Max Latency 250 ms
Sensitivity 0 for windows
Range 2 💌 g
Enable the raw data output
Write *

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



If you go back to the "System" tab again and click refresh, you should see that the accelerometer and gyroscope are now enabled and sampling. You should also now see "Game Rotation Vector (Non-Wakeup)" in the list of active virtual sensors.

General Settings						
System Virtual Sensor						
Plot1 Accelerometer(Non-Wakeup)						
Plot2 Accelerometer(Non-Wakeup)						
Plot3 Accelerometer(Non-Wakeup)						
Active Virtual Sensors Game Rotation Vector(Non-Wakeup) 💌						
BHI Working Status Normal						
FIFO Wakeup						
Watermark 0 Size 6258 bytes						
FIFO Non Wakeup   Watermark 0   Size 6258						
Application processor suspended						
BSX Library						
ODR 211 Hz						
Physical sensor working status						
Accelerometer Magnetometer Gyroscope						
Sampling Rate 200 Hz						
Range 4 g						
Power Mode Active						
Interrupt Enable						
Error Indicator No Error						
Orientation						
Roll Degree Pitch Degree						
Heading Degree						
Calibration status						
Accelerometer						
Gyroscope						
Disable Interrupt Reset System Refresh						

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017

Bosch Sensortec

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



#### 5 Streaming the data

In order to see the data output, you need to select the right sensor to plot in the graphs. Pick "Game Rotation Vector (Non-Wakeup)" from the drop-down list.



#### Last step is to click the "Start streaming button"

Ele interface Selection Panels Settings Help	
Bosch Sensortec	BOSCH
	Invented for life
Game Rotation Vector(Non-Wakeup)	General Settings
II + 😓 🔍 🔍 I I 🖪 🖸 Ass - Color - Reset	System Virtual Sensor
10000 -	Plot1 Game Rotation Vector(Non-Wakeup) -
0.8000	Plot2 Acceleromater/Non-Wakeup)
0.6000 -	Content (NorthWaterp)
0200 -	Plot3 Accelerometer(Non-Wakeup) •
00000	Active Virtual Sensors Game Rotation Vector(Non-Wakeup) -
02000 -	BHI Working Status Normal
-0.400 -	FIFO Wakeup
0.800 -	Watermark 0 👻 Size 6258 bytes
-1.0000 -	FIFO Non Wakeup
	Watermark 0 🚖 Size 6258 bytes
	Application processor suspended
III + Q   U U   I   ■ [] ⊇ Auss - Color - Reset	BSX Library
20.00	ODR 211 Hz
15.00 -	
10.00	Physical sensor working status
500	Accelerometer Magnetometer Gyroscope
5 000 -	Sampling Rate 200 Hz
	Range 4 g
1000 -	Power Mode Active
-300	Internut Enable
Accelerometer(Non-Wakeup)	Error Indicator No Error
11 + 🐼 @ @, @, ] I 🗮 🖻 🛆 Axes - Color - Reset	Orientation
20.00 -	Roll Degree Pitch Degree
15.00	Heading Degree
1000 -	Calibration status
500-	and the second s
Ê 000-j	Accelerometer Magnetometer
- 500 -	Gyroscope
-10.00	
- 15.00	Disable Interrupt Reset System Refresh
Start Strasminn	Connection status

You should now see quaternion data with 200Hz Output data rate, 4Hz Refresh rate (1/250ms = 4Hz).



Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017

Bosch Sensortec

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



# 6 Activating more than one virtual sensor

Go back to the Virtual sensor tab, but this time enable "Linear Acceleration (Non-Wakup)". Use a sample rate of 100Hz and a latency of 0ms.

General Settings	_ X
System Virtual Sensor	
Virtual Sensor Linear Acceleration(Non-Wakeup)	•
Read Info Write Info	.
Sample Rate 100 Hz (Fastest Mode) ▼ Hz	
Max Latency 0 ms	
Sensitivity 0 for windows	
Range 4 😴 g	
Enable the raw data output	
Write	

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



Back to the System tab and clicking refresh, you should now see two active virtual sensor. Note that the Accelerometer hardware is still running at 200Hz, even if the Linear acceleration is running at 100Hz.

neral settings	
vstem Virtual Sense	or
Plot1	Accelerometer(Non-Wakeup)
Plot2	Accelerometer(Non-Wakeup)
Plot3	Accelerometer(Non-Wakeup)
Active Virtual Sensors	Linear Acceleration(Non-Wakeup)
BHI Working Status	Linear Acceleration (Non-Wakeup)
FIFO Wakeup	Game (Colaron Vector(Non-Wakeup)
Watermark	0 Size 6258 bytes
FIFO Non Wakeup Watermark	0 Size 6258 bytes
Application proces	ssor suspended
BSX Library	
ODR 211 Hz	
Physical sensor wo	rking status
Accelerometer Ma	agnetometer Syroscope
Sampling Rate	200 Hz
Range	4 g
Power Mode	Active
Interrupt Enable	0
Error Indicator No	Error
Orientation	
Roll	Degree Pitch Degree
Heading	Degree
Calibration status	
Accelerometer	Magnetometer
	.11
Gyroscope	

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017



Configure the plots to see both virtual sensor, click start streaming again and you should now see both outputs simultaneously.



You should now see quaternion data with 200Hz Output data rate, Linear acceleration with 100Hz Output data rate, both at 100Hz Refresh rate.

Now it is worth noting that both game rotation vector AND linear acceleration outputs are refreshed at 100Hz since interrupt rate is dictated by the lower latency enabled sensor, in this case the linear acceleration.

<sup>©</sup> Bosch Sensortec GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties. BOSCH and the symbol are registered trademarks of Robert Bosch GmbH, Germany. Note: Specifications within this document are subject to change without notice.



# 7 Document history and modification

Rev. No	Chapter	Description of modification/changes	Date
0.1	all	Document creation	Mar. 02, 2016
1.0	all	Release	Jul. 25, 2016
1.1		Added 2 new tech. ref. codes: - 0.273.141.309 (BHI160B) - 0.273.141.310 (BHA250B)	Jan. 04, 2017

Bosch Sensortec GmbH Gerhard-Kindler-Strasse 9 72770 Reutlingen / Germany Contact@bosch-sensortec.com www.bosch-sensortec.com Modifications reserved Specifications subject to change without notice Document number: BST-BHy1-AN002-01

Bosch Sensortec

Document number BST-BHy1-AN002-01 | Revision 1.1 | Jan 2017

# **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Bosch:

BHI160 BHI160B Shuttle Board BHI160B



Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию.

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России, а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научноисследовательскими институтами России.

С нами вы становитесь еще успешнее!

#### Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург, Промышленная ул, дом № 19, литера Н, помещение 100-Н Офис 331