



# Evaluation Kit: User Manual IQ Switch<sup>®</sup> - ProxSense<sup>TM</sup> Series

IQS127 EV-Kit User Manual

## Table of Content

1	INTRODUCTION	. 1
2	MOTHERBOARD	. 1
3	SQUARE DAUGHTER BOARD	. 3
4	ROUND DAUGHTER BOARD	. 5
5	PROGRAMMING & STREAMING	. 6

### **1** Introduction

This user manual describes the IQS127 evaluation kit. The EV-kit is made in two parts, consisting of a mother board and separate plug-in boards. It is developed to facilitate application engineers and development engineers in evaluating the IQS127 capacitive proximity and touch

# sensor. LEDs are used to display the output of the device. The design of the EVkit allows for flexibility, allowing the user to use the IQS127 in direct mode, streaming mode to a PC, or use the small plug-in boards in an application circuit.

### 2 Motherboard

Figure 2.1 shows the top view of the EV-kit mother board. Its features include:

- □ Battery powered; or
- □ USB powered
- □ 15mm Diameter button

- □ Back-grid as Shield
- □ Back-grid as Ground
- □ Back-grid as Sense Plate
- □ Slide switch for programming or streaming selection (See Figure 2.3).



Figure 2.1 Top-View of EV-kit mother board.



Figure 2.2 Box header for Streaming/Programming.

The mother board includes a box header for programming and streaming the IQS127 devices through Azoteq configuration tools (CTxxx) to a PC, as well as two jumpers:

- □ W1 for measuring current
- □ W2 for back-grid selection

Figure 2.3 shows the bottom view of the mother board. The daughter boards are powered by two 3V coin cell batteries, in series, which is regulated on the mother board to 4.5V. A ground pin and mini USB connector is also available to connect and review the effect of introducing larger ground references.



Figure 2.3 Bottom view of mother board.





### **3 Square Daughter Board**

Figure 3.1 shows the top view of the square daughter board. Its features include:

- □ Prox LED
- Touch LED
- □ Small PCB layout, 10.7mm x 10.7mm
- □ Three possible assemblies:
  - Dual mode (D)
  - Shield mode (S)
  - Streaming mode (STRM)
    - Indicated by ink marking on PCB



# Figure 3.1 Top view of square daughter board. When looking from the top, IC and PCB pins are mapped one-to-one.

Figure 3.2 shows the bottom view of the square daughter board. Descriptions of the components are given in Table 3.1. The square daughter board can be wired into applications, by connecting VDDHI (pin 5),

GND (pin 2) and a sense plate (pin 6) from the application to the square daughter board. This allows the IQS127 to be tested in existing applications.



#### Table 3.1Square daughter board component descriptions.

Component	Use	Typical Value
C1,C3 <sup>1</sup>	Power Supply decoupling capacitor	1uF, 100pF <sup>1</sup>
C2,C4 <sup>1</sup>	Internal regulator decoupling capacitor	1uF, 100pF <sup>1</sup>
R1 & R2	LED current limiting resistor	2k
R3	CX series resistor (Added ESD protection)	2k
R4	Shield Pull-up resistor (only for IQS127S)	10k



Figure 3.2 Bottom view of square daughter board.

<sup>&</sup>lt;sup>1</sup> Used for added RF immunity in extreme environments (GSM band)





#### 4 Round Daughter Board

Figure 4.1 shows the top view of the round daughter board. Its features include:

- □ Bi-colour Prox and Touch LED
- □ Button on board

- □ Backlighting through the button
- □ Two possible assemblies:
  - Dual Mode
  - Streaming Mode



#### Figure 4.1 Top view of round daughter board.

Figure 4.2 shows the bottom view of the round daughter board. Component descriptions are given in Table 4.1. The round daughter board makes it extremely easy to wire the IQS127 into existing applications for testing. It needs only VDDHI (pin 5) and GND (pin 2), as it has a

button and output LEDs mounted on the PCB already. To program the round daughter board through the mother board, R3 (2k) should be moved to R4 footprint. R4 should also be placed instead of R3, to connect larger/different sense plates to the IQS127 (pin 6).

#### Table 4.1Component descriptions for round daughter board.

Component	Use	Typical Value
C1,C3 <sup>2</sup>	Power Supply decoupling capacitor	1uF, 100pF²
C2,C4 <sup>2</sup>	Internal regulator decoupling capacitor	1uF, 100pF <sup>2</sup>
R1 & R2	LED current limiting resistor	2k
R3 or R4	CX selection resistor (Added ESD protection)	2k
DS1	Bi-colour LED	N/A

<sup>&</sup>lt;sup>2</sup> Used for added RF immunity in extreme environments (GSM band)







Figure 4.2 Bottom view of round daughter board.

# 5 Programming & Streaming

The EV-Kit is by default in standalone mode. However, for some applications it is useful to evaluate the raw data of the IQS127. To be able to use this feature, the IQS127 needs to be in streaming mode.

The daughter boards can be programmed through the mother board. Begin by:

- Inserting the daughter board. (Remember to move R3 to R4)
- Move slide switch S2 to programming. See Figure 5.1



Figure 5.1 Programming switch S2.





□ Connect the EV-kit to a PC through a CT200.



#### Figure 5.2 Connect CT200 to PC (use 10 pin ribbon cable to EV-Kit).

- Burn the IQS127 into streaming mode, by using USBProg.exe (available on the website: <u>www.azoteq.com</u>).
- □ Move S2 back to SENSE after

programming. (And R3 back to R4 for the round daughter board)

□ Streaming can now be done through VisualProxSense.

The following patents relate to the device or usage of the device:

US 6,249,089 B1, US 6,621,225 B2, US 6,650,066 B2, US 6,952,084 B2, US 6,984,900 B1, US 7,084,526 B2, US 7,084,531 B2, US 7,119,459 B2, US 7,265,494 B2, US 7,291,940 B2, US 7,329,970 B2, US 7,336,037 B2, US 7,443,101 B2, US 7,466,040 B2, US 7,498,749 B2, US 7,528,508 B2, US 7,755,219 B2, US7,772,781, US 7,781,980 B2, EP 1 120 018 B1, EP 1 206 168 B1, EP 1 308 913 B1, EP 1 530 178 B1, ZL 99 8 14357.X, AUS 761094

IQ Switch®, ProxSense™, AirButton® and the IQ Logo are trademarks of Azoteq.

The information appearing in this Application Note is believed to be accurate at the time of publication. However, Azoteq assumes no responsibility arising from the use of the information. The applications mentioned herein are used solely for the purpose of illustration and Azoteq makes no warranty or representation that such applications will be suitable without further modification, nor recommends the use of its products for application that may present a risk to human life due to malfunction or otherwise. Azoteq products are not authorized for use as critical components in life support devices or systems. No licenses to patents are granted, implicitly or otherwise, under any intellectual property rights. Azoteq reserves the right to alter its products without prior notification. For the most up-to-date information, please contact ProxSenseSupport@azoteq.com or refer to the website: www.azoteq.com



Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию.

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России, а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научноисследовательскими институтами России.

С нами вы становитесь еще успешнее!

#### Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург, Промышленная ул, дом № 19, литера Н, помещение 100-Н Офис 331