

# Series 6 Data Sheet Quad Sum and Difference Amplifier Part Description QP50-6-18u-SD2 US Order # 10-027 International Order # 501102





#### DESCRIPTION

The **QP50-6-18u-SD2** is a quad photodiode array with current-to-voltage amplifiers that provide bottom minus top and left minus right difference signals. Additionally the **QP50-6-18u-SD2** provides a signal that is the sum of all four quadrant diode signals. The difference signals are voltage analogs of the light intensity difference sensed by the pairs of photodiode elements in the array. The board has a 7 pin connector attached for easy hook up.

### **OPTIONS**

- Can be purchased without connector, use order # 10-007.
- For alternate gap size, see data sheet QP50-6SD2 for 42  $\mu m$  gap version.
- Also available with quad detector active area sizes ranging from 1mm<sup>2</sup> to 20 mm<sup>2</sup>.

#### **ABSOLUTE MAXIMUM RATING**

| SYMBOL           | PARAMETER                                | MIN  | MAX  | UNITS |  |  |  |  |
|------------------|--|------|------|-------|--|--|--|--|
| T <sub>STG</sub> | Storage Temp                             | -15  | +100 | °C    |  |  |  |  |
| Тор              | Operating Temp                           | 0    | +70  | °C    |  |  |  |  |
| Vs               | Power Supply Voltage<br>Recommended ±15V | ±4.5 | ±18  | V     |  |  |  |  |
| VR               | Applied Bias Voltage*                    | 0    | 15   | V     |  |  |  |  |

CONNECTION



# SPECTRAL RESPONSE @ 22°C



## ELECTRO-OPTICAL CHARACTERISTICS @ 22° C

| SYMBOL                     | CHARACTERISTIC               | TEST CONDITIONS                                 | MIN | ТҮР        | MAX | UNITS          |
|----------------------------|------------------------------|---|-----|------------|-----|----------------|
| Vo                         | Output Voltage (all outputs) |   |     | +Vs -3     |     | v              |
|                            |                              |   |     | $-V_s + 3$ |     |                |
| lo                         | Output Current Limit         | $V_{s} = \pm 15 \text{ V}; V_{R} = 0 \text{ V}$ |     |            | 25  | mA             |
|                            | Slew Rate                    | $V_s = \pm 15 V; V_R = 0 V$                     |     |            | 10  | $V/\mu s$      |
|                            | Theoretical noise            | $V_{s} = \pm 15 \text{ V}; V_{R} = 0 \text{ V}$ |     | 15         |     | $nV/\sqrt{Hz}$ |
| $\Delta f_{-3\mathrm{dB}}$ | Bandwidth**                  | $V_s=\pm~15$ V; $V_R=5$ V; $\lambda=880~nm$     |     | 250        |     | kHz            |

\* actual bias voltage to photodiode: pad 1 voltage times 0.91. Do not apply negative voltages to pad 1.

\*\* dependant on bias voltage

Disclaimer: Due to our policy of continued development, specifications are subject to change without notice.

# NIR & visible pulsed light

positioning and tracking

**APPLICATIONS** 

Laser beam centering





# **APPLICATION NOTES**

#### **Beam Size**

The light spot applied to the QP50-6-18u-SD2 must be smaller than the diameter of the quadrant photodiode array. The detector active area has a diameter of 7.8 millimeters. If the light spot is too large, it may be reduced to fit the photodiode array by use of a lens. A decrease in output signal strength is observed as the light spot crosses the separation boundary of the quadrants, usually referred to as the "gap". This effect is more pronounced as the diameter of the light spot decreases, as a larger percentage of the light spot's power falls within the non-active gap. For this reason, the minimum light beam diameter should be a least one millimeter. A lens may be used to increase the beam diameter.

#### **Photodiode Bias Operation**

The QP50-6-18u-SD2 array may be operated either in the zero bias or the reverse bias mode. Pin 1 is connected, via a resistor divider, to the noninverting input of a voltage follower operational amplifier. This line may be left unterminated, grounded or connected to a voltage source of zero volts to operate in the zero bias mode. If the photodiode bias line is connected to a positive voltage source (but less than Vcc), then the photodiode elements in the array will be biased at 0.91 x VBias. Do not connect Pin 1 to negative voltages, as this will forward bias the photodiode array, making it inoperable and possibly damaging the circuit.

### Use of Sum and Difference Signals for Alignment

The sum output signal may be used to help preliminary alignment of the QP50-6-18u-SD2 to the source light beam. First, the beam or the QP50-6-18u-SD2 is adjusted for maximum sum output signal. Second, the beam or QP50-6-18u-SD2 is adjusted until the L-R and B-T signals are at minimum. This procedure results in the beam being centered on the quad photodiode array.

## Signal Null Detector for Servo Applications

A common application for the QP50-6-18u-SD2 is a signal null detector as part of a servo system that maintains the position of a light beam. Errors in beam position are reported by the QP50-6-18u-SD2 and may be used to adjust a positioning device that restores the beam or the beam's source to a null position.

#### **Speed of Response**

Increasing the photodiode bias voltage will increase the speed of the QP50-6-18u-SD2. Operating with zero reverse bias is sufficient for many applications (-3dB is around 150 kHz at 880 nm). As noted above, Pin 1 is provided for applying positive bias voltage to the quad for higher frequency response. Care should be taken not to exceed the circuit common mode values and the breakdown voltage of the quad photodiode. See Absolute Maximum Ratings on page one for maximum values.

#### **Temperature Considerations**

The operation temperature must be between 0 to 70 °C. For best resolution the temperature should be kept at or below 25 °C. Thermal gradients across the detector will cause position errors and should be avoided.

## Offsets

Precision components are used in the circuitry but as much as 10 millivolts of dark offset may still be present in the outputs. If this causes a problem the offsets should be removed externally.



USA

First Sensor Inc. 5700 Corsa Avenue, #105 Westlake Village, CA 91362 USA T + 818 706-3400 F + 818 889-7053 contact.us@first-sensor.com www.first-sensor.com

#### International sales

First Sensor AG Peter-Behrens-Str. 15 12459 Berlin, Germany T + 49 30 6399 2399 F + 49 30 639923-752 sales.opto@first-sensor.com www.first-sensor.com



Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию.

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России, а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научноисследовательскими институтами России.

С нами вы становитесь еще успешнее!

#### Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург, Промышленная ул, дом № 19, литера Н, помещение 100-Н Офис 331