

# UG164: Thunderboard<sup>™</sup> React (RD-0057-0201) User's Guide

The Thunderboard<sup>TM</sup> React is a cloud-connected, *Bluetooth*<sup>®</sup> Smart-enabled, sensor-driven platform that enables customers to demo, evaluate, and develop their own unique applications.

It leverages Silicon Labs' BGM111 Bluetooth Smart module as a wireless system-on-achip (SoC) to collect to various sensor data and deliver it to the cloud through Bluetooth Low Energy (BLE)-enabled iOS/Android mobile apps. This document provides an overview of the kit including hardware, software application, cloud platform, and mobile app. It also contains instructions and guidelines to evaluate the simplicity of adding Bluetooth to your project to connect to the cloud. steening

#### KEY POINTS

- Low-cost, Bluetooth Smart solution that collects and delivers data to the cloud
- Hardware includes BGM111 Bluetooth Smart module linked to sensor inputs
- ThunderBoard React connects to BLEenabled iOS/Android mobile apps
- Apps connect to a cloud-based multi-client, real-time synchronization database

# 1. Introduction

Thunderboard<sup>™</sup> React is a low-cost, BLE solution that collects and delivers data to the cloud.



Figure 1.1. System Application Diagram

The Thunderboard React is a great demonstration and evaluation tool to easily add BLE connectivity to a sensor or actuator application. The mobile app seamlessly communicates between the Thunderboard and the cloud database to visualize sensor data collected or control the LED states on the Thunderboard React hardware. Individual components of the Thunderboard React can be easily integrated and modified in order to add BLE-to-cloud connectivity for a user's particular application.

All instructions, collateral, and source files for this solution can be found here: http://www.silabs.com/thunderboardreact.



Figure 1.2. ThunderBoard React

# 2. Quick Start

This section describes how to quickly get started using the Thunderboard React with its mobile apps and cloud database. For detailed instructions, refer to Section 4. Operation.

- 1. Download the mobile app.
  - a. Links to the iOS and Android mobile app can be found here: http://www.silabs.com/thunderboard
- 2. Supply power to the Thunderboard React.
  - a. Remove the battery tab.
  - b. Set SW3 switch where its toggle is closest to Vbat.
- 3. Connect the Thunderboard React to the mobile app.
  - a. Launch the mobile app on the phone, ensuring the phone's Bluetooth radio is enabled.
  - b. On the Thunderboard React, press the SW-0 button. The blue LED (LED-B) will blink to indicate it is sending a beacon advertisement.
  - c. Locate the device on the app which should display "Thunderboard React #nnnnn", and click on the device in the mobile app to connect to it.
  - d. If the device successfully pairs, the mobile app displays available demos and the blue LED on the hardware will stop flashing.
- 4. Select the demo.
  - a. For this quick start, select the I/O demo.
  - b. Once the demo is activated, it will take you to the demonstration screen.
- 5. Use the demo.
  - a. Press the SW-0 and SW-1 on the Thunderboard React and witness its visual response along the top area of the phone screen.
  - b. On the mobile app itself, press the two buttons in the middle and witness that the Thunderboard React's blue LED (LED-B) and green LED (LED-G) are statically illuminated.
  - c. Press both buttons again on the mobile app to extinguish the LEDs.
- 6. Stream to the Cloud.
  - a. Ensure the mobile phone has the ability to connect to the internet either through Wi-Fi or cellular connection for this portion of the demonstration.
  - b. While in the I/O demo, along the top portion of the screen, drag the toggle switch to activate cloud streaming.
  - c. Data is now being sent from Thunderboard React to the mobile app to a cloud database on the internet.
  - d. To see the live stream, select the share icon (up arrow in an open box) next to the toggle switch on the mobile app, and then select the phone's mobile browser. This will launch the browser, placing the mobile app in the background while still streaming data to the cloud.
  - e. The switch and LED real-time data will now be shown in the browser.
  - f. While still connected, press the buttons on Thunderboard React and witness the resulting change in states on the cloud.
- 7. Share the Cloud stream session.
  - a. While streaming, in the mobile app, select the share icon and then select an email, message client, or social media tool. This should launch the tool with a pre-populated message containing a hyperlink to the streaming session.
  - b. Send the message to another device client (such as a laptop or another mobile phone with a web browser).
  - c. From the device client, launch the hyperlink and witness the simultaneous cloud session being displayed on this device while the original phone is connected to the Thunderboard React. The cloud platform supports real-time data synchronization across multiple clients.
- 8. End the cloud stream.

a. Return to the mobile app and move the upper toggle switch to disable the cloud stream session.

- 9. Turn off the device.
  - a. On the Thunderboard React, move the SW3 toggle switch to where it is the closest to Vext.
- 10. Review the cloud session.
  - a. If emailed, this provided link will display the resulting summary of the cloud streaming session.
  - b. This link will be available for 30 days.

# 3. Overview

The Thunderboard React solution provides:

- A low-cost, Bluetooth-enabled sensor platform
- Open-source, native iOS, and Android mobile apps
- · A cloud database (Google Firebase) that supports multiple clients

This solution allows customers to demo, evaluate, and develop their own unique applications.

#### 3.1 Part Number

The part number convention is RD-XXX-YYYY, where:

- RD Reference Design
- XXXX Reference Design Number
- YYYY Reference Design Component

This document will use the reference design number (RD-XXXX) when describing the complete design, and the reference design component (RD-XXXX-YYYY) when describing a specific component.

The following table provides a description and PCB marking for each part number.

Note: Some cases lack sufficient space on the PCB, and an internal "IST" marking appears on the PCB instead of the "RD" part number.

# Table 3.1. Part Numbers and Description

Part Number	PCB Marking	Description
CARKIT	N/A	Cloud-connected, Bluetooth-enabled pinewood derby car kit with included RD-0057-0101 Thunderboard React Evaluation Board
RD-0057-0201	N/A	Thunderboard React Bluetooth Sensor Reference Design Kit with BGM111, Si7021, Si7201, and Si1133.
RD-0057-0101	IST-A0057 Rev 2.0	Thunderboard React Bluetooth Sensor Evaluation Board with BGM111, Si7021, Si7201, and Si1133.

#### 3.2 Reference Design Kit

#### 3.2.1 RD-0057-0201 Kit Contents

- · Thunderboard React evaluation board
- · Quick start card to obtain the latest design collateral

# 3.2.2 RD-0057-0101 Kit Contents

- Thunderboard React evaluation board
- Car şhell
- · Pinewood car base
- Wheels and axles
- Metal screws and stand-offs

• Quick start card to explain assembly and obtain the latest design collateral

hendesidi

#### 3.3 Hardware Features

The ThunderBoard React hardware platform contains the following features:

- Silicon Labs Blue Gecko BGM111 Bluetooth<sup>®</sup> Smart Module
  - 32-bit ARM<sup>®</sup> Cortex-M4 CPU
  - · 256 KB Flash
  - 32 KB RAM
  - TX power: up to +8 dBm
  - RX sensitivity down to -93 dBm
- Silicon Labs Si7021 relative humidity and temperature sensor
  - Temperature sensor accuracy: ±0.4 °C
  - Humidity sensor accuracy: ±3% RH
  - I2C interface
- · Silicon Labs Si1133 ambient light and UV sensor
  - Ambient light sensor range: 1 to 128 kilo lux
  - UV index sensor range: 1 to 11
  - · I2C interface
- · Silicon Labs Si7201 omni-polar, hall-effect sensor
  - · Operating point: 30 Gauss max
  - Release point: 10 Gauss min
  - · Push-pull output
- Invensense MPU-6500 6-axis motion sensor
  - · 3-axis accelerometer
  - 3-axis gyroscope
  - · I2C interface
- Two momentary buttons (SW-0, SW-1)
- Blue and green LEDs (LED-B, LED-G)
- · 10-pin 0.050", 1.27 mm mini-simplicity debug connector
- PCB footprint for up to 8Mb external flash device
- · Break-out pin pads to connect to BGM111 GPIOs
- CR2032 coin cell battery slot



Figure 3.1. Thunderboard React Hardware Diagram

0esic

en

#### 3.4 Thunderboard React Firmware Features

The Thunderboard React firmware application contains the following features:

- Pre-compiled and source application firmware
- · Sleep mode for battery savings
- · Beacon notification to interface to a beacon-compatible mobile app
- Bluetooth-compatible GATT service profiles

#### 3.5 ThunderBoard Mobile App Features

The Silicon Labs ThunderBoard mobile apps contains the following features:

- Bluetooth-compatible connectivity support
- Beacon notification support
- · iOS app uses native Swift code
- Android app uses native Java code
- · Source code can be obtained at: http://www.GitHub.com/SiliconLabs

#### 3.6 ThunderCloud Software Features

The Thunderboard React's web client contains the following features:

- · Leverages Firebase by Google, a scalable cloud solution that can rapidly deploy:
  - · Real-time synchronization database capable of supporting multiple clients
  - · User authentication security
  - Web hosting
- ThunderCloud uses ReactJS framework for its overall architecture:
  - Leverages npm as a package manager
  - · Alt.js for the flux implementation
  - · React Router for routing within the app
  - · D3.js For data-driven charts
  - · LESS for CSS pre-processing
  - · Gulp for building and minifying code
- · These tools and architecture allow for:
  - · Simultaneous connection of multiple Thunderboard React devices via mobile app
  - · Multiple device clients synchronously connected to a single cloud session
  - · Persistence storage of past cloud sessions (up to 30 days).
- Source code can be obtained at: http://www.GitHub.com/SiliconLabs.

# 4. Operation

This section describes the various operational modes of the Thunderboard React hardware, the Silicon Labs ThunderBoard mobile apps, the Thundercloud database and how each interact to create a low-cost, BLE-enabled, cloud-connected solution. For this section, the screen captures will be using the iOS mobile app even though the instructions apply to both mobile apps. For features where the Android mobile app operates differently than iOS, these instructions will also be provided.





#### 4.1 Download the Mobile Apps

Specific links to the iOS AppStore and Google Play Store to obtain the free Silicon Labs ThunderBoard mobile apps can be found here: http://www.silabs.com/thunderboard-react.

#### 4.2 Supply Power to the Thunderboard React

If present, remove the battery tab from the battery holder. Set the SW3 switch where its toggle is closest to Vbat to supply power to the device. Setting the toggle closest to Vext will power-down the device. At power up, the device will enter a self-test mode. If it discovers an error, it will emit alternating green and blue LEDs. For more information on the self-test, refer to the firmware section. If changing CR2032 batteries, ensure the positive side of the battery (+) is aligned to the metal battery tab's plus marking (+).





The hardware can additionally be powered via the mini-simplicity debug connector (J3). To do this, ensure the SW3 switch is set to where its toggle is closest to Vext.

#### 4.3 Connect Thunderboard React to the Mobile App

Once the mobile app is successfully installed on the phone and the hardware is powered, the following sub-sections will describe how to successfully pair them.

#### 4.3.1 Launch the Mobile App

Upon selecting the Silicon Labs ThunderBoard icon on an iOS/Android mobile phone, the app will launch with this introduction screen for a few seconds, and will then look for nearby Thunderboard React devices:



00s

#### 4.3.2 Enable Beacon Notification

On the Thunderboard React, press either the SW-0 or SW-1 button. The LED-B will blink to indicate it is sending an advertisement beacon. To save power, the beacon will only be enabled for 30 seconds. If it is necessary to re-activate the BLE beacon, re-press one of the buttons.



Figure 4.4. LEDs and Buttons on Thunderboard React

NotRecommendedto

#### 4.3.3 Looking for Devices

After the launch screen completes, the app will display various informal messages as it is looking for a ThunderBoard device. Valid screens should either have the message "Looking for Devices" or display the found device(s).



Once a device is found, it can be selected as described in the next section. The detected device will display its unique name and measured received signal level from the perspective of the mobile phone.

If "Bluetooth is Disabled" is displayed, go to the mobile phone's settings and ensure its airplane mode is not enabled and the Bluetooth radio is enabled. If "No Devices Found" is displayed, ensure the Thunderboard React is in nearby range, is powered, and its Blue LED is flashing.



#### 4.3.4 Selecting From Found Device(s)

After Thunderboard React device(s) have been found, tap on the desired device to connect to it.

A successful connection will display available demos, and the device's information will show along the bottom border. On the hardware, the blue LED should stop flashing and the green LED should flash once.



Figure 4.7. App Screen after Successful Connection

From this screen along the bottom border, the device's unique name will display along with its estimated battery health. Clicking the back arrow from this screen will disconnect (un-pair) the device from the mobile app.

To enable opening the app using the advertisement beacon, click on the gear icon for global settings, as described in the user app settings section.

Recc

#### 4.4 User App Settings

User-defined settings can be configured in the looking for devices or choose demo screens.

-102 AT&T 🗢	8:43 ам Settings	7 🏾 🖁 85% 💶
PERSONAL INFO	Jettings	Edit
TERSONAL INFO		Eult
Name		
Title		
Email		
Phone		
PREFERENCES		
Measurements		Metric US
Temperature		C F
Motion Demo Mo	dal	Board Car
MOLION DENIO MO	uer	Board Cal
Beacon Notificatio	ons	OFF >
Version 1.0	(405)   © Silic <i>o</i>	n Labs 2016
		χŲ
Eiguro 44	8. User App	o Sottings

While in this screen, the user can specify their contact information that will then be displayed when sharing links. The user can also specify desired measurement and temperature units, as well as which 3D model to render in the motion demo (ThunderBoard or React-Car). The user can also enable beacon notifications that will alert the app when a beaconing Thunderboard React is within the radio's signal range and available for connection.

#### 4.5 Configuring Beacon Notifications

Within the User App Settings, a user can enable/disable beacon notifications. When these notifications are enabled, a known Thunderboard React can be allowed to notify the mobile app of its nearby presence and once clicked, the app will automatically pair with the device and directly open the choose demo screen. To allow or remove a Thunderboard React, click on ALLOW or REMOVE for that particular device.

Note: To allow a device it must have already been connected to the app.

	8:45 AM Beacon Notificatio	≁ ♥ \$ 85% <b>==</b> )• ns
You'll get a r	notification when an allo is on and in range. This	wed Bluetooth
Allow Beaco	n Notifications	
ALLOWED DI	EMO DEVICES	
OTHER DEM	D DEVICES	
Thunder Rea	act #29016	ALLOW
Thunder Ser	nse #30060	ALLOW
Thunder Ser	nse #30136	ALLOW
Thunder Rea	act #29885	ALLOW
Thunder Ser	nse #30153	ALLOW
<b>T</b> I I C	nse #30635	ALLOW

Figure 4.9. Device Beacon Notification Settings

For iOS devices: In iOS, beacon notifications alert a mobile phone that it is within a nearby beacon. As a result, the phone's OS can sometimes inhibit notifications so as to avoid flooding the mobile phone with continual notifications as it resides on a boundary of a beacon's radio signal range. The best method to reliably demonstrate this feature is to have the allowed Thunderboard React device powered off, power it up, and then press the SW0 or SW1 button. Within seconds, the beacon should trigger a notification and the dialog box will allow a user to open the mobile app.

For Android devices: As of Android OS version 4.4, beacon notifications with this demonstration only work if the mobile app is launched and is at least residing in the phone's background.

#### 4.6 Select a Demo

Once the mobile app is connected (paired) to a Thunderboard React, it will display the following available demos:

- · Motion: Uses the accelerometer, gyroscope, and hall-effect sensors
- · Environment: Uses the temperature, relative humidity, ambient, and UV sensors
- · I/O: Uses the two momentary push buttons and two LEDs

The next sub-sections will describe each demo and how to operate them. The subsequent sub-sections will then describe how to stream each of these demos to the cloud where they can be viewed and shared by multiple device clients. Both live and completed streamed demo sessions can be viewed by multiple clients for up to 30 days.

To select a specific demo, click on it.



#### 4.6.1 Motion Demo

STREAM TO CLOUD     ORIENTATION   X:   0.1 g   Y:   Y: <td< th=""></td<>
X:       8 °         Y:       -8 °         Z:       37 °         ACCELERATION       ACCELERATION         X:       0.1 g         Y:       1.1 g         P:       0.0 g         ft/s
CALIBRATE     DIA.:     1.19*       SPEED     0     0       ft/s     rpm

#### Figure 4.11. Motion Demo Screens

The motion demo can demonstrate the following:

- · 3-axis orientation, shown numerically and visually via a 3D rendered model
- · 3-axis acceleration, shown numerically
- Speed and distance via the hall-effect sensor's output displayed as a CSC (Cycling Speed and Cadence) service

For the rendered 3D model, either the ThunderBoard or the React Car can be displayed in the demo. To change what is displayed, go to the device settings and select the desired model, as shown in 4.4 User App Settings.

For orientation and acceleration, the Thunderboard React's axes can be calibrated. To do so, rest the Thunderboard React in an upright position (top of the device facing up). While leaving the device untouched and not moving, click on "calibrate". The mobile app will perform a calibration calculation for a few seconds, displaying a pop-up message while it is doing so until it completes. Once completed, move the Thunderboard React and notice the device is now aligned to the 3D model on the mobile app screen. The specifics of the device-to-app refresh rate as well as the angle values shown in the app can be found in the firmware section.

For speed and distance, the hall-effect sensor is to be paired with a magnet. The firmware is designed to display this sensor as a CSC service, which means it will assume every nearby magnetic sensor contact point will be counted as a full wheel revolution. From each revolution, it will determine a speed and distance based on a specific wheel diameter commonly found in pinewood derby races. For more information on refresh rates and speed values, refer to 6. Firmware.

#### 4.6.2 Environment Demo





This demonstration uses the Si1133 and Si7021 to display the following environment sensors (with range).

#### Table 4.1. Environment Demo Measurements

Sensor	Туре	Min	Мах	Unit
Si1133	Ambient Light	1	99,999	lux
	UV Index	1	15	_
Si7021	Temperature <sup>1</sup>	-40	85	С
	Relative Humidity	0	100	%
Note: 1. Farenheit equivalen	ts can also be displayed via the user a	op setting.		

#### 4.6.3 I/O Demo



For a simple demonstration, the mobile app can show how a button press on the device can result in a change on the mobile app screen, and vice versa. Upon pressing either SW-0 or SW-1, the mobile app will animate the two circle icons along the top area of the demo screen. Upon pressing either the left or right icons in the lower section of the screen, the blue and green LEDs on Thunderboard React can be statically illuminated.

silabs.com | Smart. Connected. Energy-friendly.

#### 4.7 Stream to the Cloud

While connected to Thunderboard React, the mobile app can simultaneously stream the live demo session to the cloud where multiple device clients can view its live stream. The same link will also display the final results of the stream, and will remain available for later viewing for up to 30 days. All available demos can be streamed to the cloud.

To stream to the cloud while in a demo, move the toggle stream to ON (located along the top right area of the mobile app). The demo's results are now being simultaneously transmitted on the app screen and streamed into the cloud. While in this streaming mode, the session can be shared via a link (see 4.7.1 Send a Link to the Cloud Session), or it can be immediately viewed from the same mobile device by using its mobile browser and placing the app in the phone's background (see 4.7.2 View the Cloud Session).



#### 4.7.1 Send a Link to the Cloud Session

Once a cloud stream session is enabled, the user has the ability to share the stream to others and view the session from the cloud on the same mobile device. To do any of these options, select the share icon along the top right of the app screen (the share icon looks like an up arrow out of an open box). Upon selecting, the mobile app will display a pop-up window with various available options.

STREAMING TO CLOUD ORIENTATION X: 8 ° Y: -8 °	STREAMING TO CLOUD ORIENTATION X: 8 ° Y: -8 ° Tap to share with AirDrop	STREAMING TO CLOUD ORIENTATION X: 8 ° Y: -8 °	STREAMING TO CLOUD ORIENTATION X: 8 ° Y: -8 ° Tap to share with AirDrop	X: 8 ° Y: -8 ° Tap to share with AirDrop	STREAMING TO CLOUD ORIENTATION X: 8° Y: 8° Y: 8° Tap to share with AirDrop Raman	-102 AT&T ᅙ	8:48 AM	l 🚽 🍯 🔱 83% 💼 🕨
ORIENTATION X: 8 ° Y: -8 °	ORIENTATION X: 8 ° Y: -8 ° Tap to share with AirDrop	ORIENTATION X: 8 ° Y: -8 ° Tap to share with AirDrop	ORIENTATION X: 8 ° Y: 8 ° Tap to share with AirDrop	ORIENTATION X: 8 ° Y: -8 ° Tap to share with AirDrop	ORIENTATION X: 8 ° Y: -8 ° Tap to share with AirDrop Raman			
X: 8° Y: -8°	X: 8 ° Y: -8 ° Tap to share with AirDrop	X: 8 ° Y: -8 ° Tap to share with AirDrop	X: 8 ° Y: -8 ° Tap to share with AirDrop	X: 8 ° Y: -8 ° Tap to share with AirDrop	X: 8° Y: -8° Tap to share with AirDrop Rs Raman			
	Tap to share with AirDrop	Tap to share with AirDrop	Tap to share with AirDrop	Tap to share with AirDrop	Tap to share with AirDrop Raman			
			RS	RS	RS Raman			Y: -8°
		Message Add to Notes Mail Twitter	Message Add to Notes Mail Twitter F	Message Add to Notes Mail I Wilter		**		
		Message Add to Notes Mail Twitter	Message Add to Notes Mail Twitter	Message Add to Notes Main I witter		Save to	Copy S	afari More
Raman Message Add to Notes Mail Twitter t Save to Copy Safari More	Message       Add to Notes       Mail       Twitter       F         Save to       Copy       Safarit       More	Save to Copy Safari More	Save to Copy Safart More	Save to Copy Safari More	Save to Copy Safari More	Бгорвох		
Raman Message Add to Notes Mail Twitter	Message       Add to Notes       Mail       Twitter       F         Save to       Copy       Safarit       More	Save to Copy Safari More	Save to Copy Safart More	Save to Copy Safari More	Save to Dropbox		Cance	
Raman Message Add to Notes Mail Twitter t Save to Copy Safari More	Message       Add to Notes       Mail       Image: Composition of the second	Save to Dropbox	Save to Dropbox	Save to Dropbox	Dropbox		-77	

Figure 4.15. Sharing the Cloud Session

To share the link, select from a multitude of sharing options (e.g., Email, Twitter, Facebook). For this document, the SMS message and the email link will be described.

To share via email in iOS, select the email client and a draft email will appear. Add a recipient(s), edit the draft email as needed, and send the email. On completion, the phone will return the user to the mobile app.

JotRecon



Figure 4.16. Sharing the Cloud Session via Email

To share via SMS message in iOS, select the message client and a draft message will appear. Add a recipient(s), edit the draft as needed, and send the message. Upon completion, the phone will return the user to the mobile app.

	••000	(¢		4	1:13 PM	N		* 7	75% 🔳 )
			C	New	Mes	sage		C	ancel
	To:	C							(+)
		5							
		Her	e is tl	ne lin	k to a	acces		ır	
		Silic	con La ced d	abs D	emo	Devi	се		
c		Syll	ceuu	iata. I	mp./				
$\sim$									
	0								Send
	q	w	e	r t	: ] }	/ L	<u>ا</u>	i c	p p
$\langle O^{\vee} \rangle$	а	s	d	f	g	h	j	k	I.
	Ŷ	Z	X	С	V	b	n	m	$\bigotimes$
*	123		s	bace		0	•	re	turn

Figure 4.17. Sharing the Cloud Session via Message

#### 4.7.2 View the Cloud Session

While in the mobile phone with the app streaming to the cloud, open the share icon and select the mobile browser to view the live session directly from the cloud. If connected to the internet, the screen will now display a mobile view of the cloud streaming session. While in this mode the app will move to the background and maintain the connections to the connected Thunderboard React device and the cloud database in the internet. The cloud database is a responsible web design and will render the session based on the screen's size. For live streams, the cloud view will show the last 30 seconds of collected data. Once a live stream ends, the same link will display the entire stream session in a summary format. Recommended for New Desi

# UG164: Thunderboard<sup>™</sup> React (RD-0057-0201) User's Guide Operation



#### 4.7.3 View from Another Client

While viewing the cloud session from the same mobile client is a great way to demonstrate the cloud-connectivity of the Thunderboard React platform, one of the innovative features of this demo is its ability to support multiple clients from its cloud database using Firebase.

To view from another device client, this client should be sent a shared link. The other device(s) can then click on the link and open up a separate, synchronized view from the cloud database.



#### 4.7.4 View Past Sessions

Each device's last ten sessions that have been shared to the cloud can be viewed from the cloud screen. To do so, click on "Past Sessions" in the lower center section of the screen. These past sessions will be available for 30 days from the end of their session time.



# 5. Hardware

This section describes the key aspects of the Thunderboard React hardware design.



#### 5.1 Mini-Simplicity Debug Connector

The Thunderboard React includes a 10-pin mini-simplicity debug connector (J3) to allow a user to develop, program, and debug the firmware application with the hardware. For more information on the firmware application, refer to 6. Firmware.



Figure 5.3. J3 Mini-Simplicity Debug Connector

## Table 5.1. Mini-Simplicity Debug Connector Pin Assignments

Pin	Name
1	VAEM
2	GND
3	RST
4	VCOM_RX
5	VCOM_TX
6	SWO
7	SWDIO
8	SWCLK
9	PTI_FRAME
10	PTI_DATA
Note:	

1. The connector on the hardware is a keyed male 10-pin 0.050" (1.27 mm), 2×5 array.

)

es

 $\mathbf{O}$ 

Desi

#### 5.2 User-accessible Pads

For further design modifications, the hardware also includes solder pads that can be used to interact with the design with external circuitry. These can be found bordering the BGM111 footprint, and are labeled along the bottom of the printed circuit board.



Figure 5.4. User-accessible Pad Arrays

#### Table 5.2. User-accessible Pad Pin Assignments

Schematic Pins	BGM111 Pins	Schematic Signals
TP16	PD13	_
TP17	PD14	_
TP18	PD15	
TP19	PA2	LED-B
TP21	PA3	SW0
TP22	PA5	
TP23	PF7	SW1
TP24	PF6	LED-G
TP25	VMCU	PWR
TP26	GND	GND
TP27	VMCU	PWR
TP28	GND	GND
Note:	·	

1. Additional test points found along the printed circuit board: PF3, PF4, PF5, SCL, SDA, VBAT, GND.

# 6. Firmware

This section describes the ThunderBoard-React application firmware.

#### 6.1 Obtaining the Firmware Application

The firmware for the ThunderBoard-React can be found within the Silicon Labs Bluetooth Smart SDK as a sample application. This sample application is provided as both a pre-compiled binary and as a source project that can be opened can be opened and built with Simplicity Studio.

#### 6.2 Tools Needed for Firmware Modification

The following additional hardware and software is needed to modify the firmware application on the ThunderBoard-React evaluation board:

#### Hardware Tools:

- · Wireless STK with supplied USB-to-mini-USB cable
- SLSDA001A adapter (includes 10-pin ribbon cable).

#### Software Tools:

- Simplicity Studio v4 or later with latest Wireless Products package and the Bluetooth Smart SDK v2.0.0 software stack or later installed
- IAR Embedded Workbench for ARM 7.60 or later

Recommended

#### 6.3 Simplicity Studio Tool Setup

To ensure Simplicity Studio has the latest wireless packages and Bluetooth Smart SDK installed, click on the Update Software icon in the upper left corner:



Figure 6.1. Update Software Icon

Click the *Basic Installer* button and go to the Select By Product Group tab. Make sure the Wireless Products box is checked and click *Next*.



Figure 6.2. Verify Wireless Product Installation

Make sure the Bluetooth Smart SDK box is checked and click Finish.

en -	
Installation Options	
Select the options you would like to use within Simplicity Stud	io.
Filter by product selection in previous step	
Recommended (based on selections in previous step)	
Recommended (based on selections in previous step)	
Bluetooth Smart SDK v1.1.0 - 1.1.0	Silicon Labs Connect - 1.0.5.0
Silicon Labs Bluetooth Smart SDK v1.1.0	Wireless integration support for Silicon Labs Connect
Install Location Browse	Install Location Browse
Silicon Labs RAIL Stack - 1.2.1.0 Wireless integration support for Silicon Labs RAIL Stack Install Location Browse	FOLVEN
Selected Products: 3 Download Size: 177	MB Required Disk Space: 415 MB
mende	
? Custom Install	Back Next > Finish Cancel
Figure 6.3. Verify Blueto	oth Smart SDK Installation

The IAR ARM compiler is used to compile the ThunderBoard-React sample application. The compiler is included in IAR Embedded Workbench for ARM (EWARM), which needs to be installed. To point Simplicity Studio to your IAR installation, go to Settings (Green cog wheel in upper left hand corner of the Launcher perspective). Then navigate to IAR Embedded Workbench and set the Path to the IAR Embedded Workbench IDE installation directory.

# UG164: Thunderboard<sup>TM</sup> React (RD-0057-0201) User's Guide

type filter text	IAR Embedded Workbench Setup
b General b C/C++	Installed IAR Toolchains
⊳ C/C++ ⊳ Help	IAR Toolchain for ARM - (7.x) (iar.sdkprovider.arm)
IAR Embedded Workbenc	Path to the IAR Embedded Workbench IDE installation directory
<ul> <li>Install/Update</li> <li>Network Analyzer</li> <li>Network Applications</li> </ul>	C:/Program Files (x86)/IAR Systems/Embedded Workbench 7.4/
<ul> <li>Run/Debug</li> <li>Simplicity Studio</li> <li>Team</li> </ul>	FOLVENDESI
۲ III ا	Restore Defaults Apply
?	OK Cancel
	Figure 6.4. IAR Embedded Workbench Path
Recon	
K-	

#### 6.4 Open ThunderBoard-React Project in Simplicity IDE

In the Simplicity Studio Launcher screen, select the Solutions tab on the left-hand side and click the Add Devices button.

	Sign In •   • Device   • Solutions     • New Solution     • Add Device	ces
	Figure 6.5. Add Devic	ces
the Add Devices box, search for the T	ThunderBoard React RD-0057-0201 ki	it, select it, and click OK.
🛹 Add Devices		
Connected Devices          EFR32BG1B232F256GM48         Don't have a device? Find and in	Selecte	emove Remove All ed Devices
thu		
Kits Thunderboard React RD	0-0057-0201	
Boards     ThunderBoard React (Ri		OK Cancel

Figure 6.6. Add ThunderBoard-React

Once the ThunderBoard-React kit is added and selected, you should see all available resources—like Documentation, Compatible Tools, etc.—in the Simplicity Studio main screen.

#### UG164: Thunderboard<sup>™</sup> React (RD-0057-0201) User's Guide Firmware





Click the New Project button. Select the Silicon Labs Bluetooth Smart Framework and click Next. Select the SOC – ThunderBoard React sample application and click Next.

silabs.com | Smart. Connected. Energy-friendly.

elect Application Select either a blank application or a sample application. Imple Application SOC - Thermometer The Health Thermometer profile enables a Collector device to connect and interact with a Thermometer sensor for use
mple Application
SOC - Thermometer
The Health Thermometer profile enables a Collector device to connect and interact with a Thermometer sensor for use
in healthcare applications. This Silicon Labs Bluetooth Smart application demo implements the Thermometer (GATT
Server) Role of the Health Thermometer Profile. The device acts as a connection Peripheral.
SOC - iBeacon
The purpose of the iBeacon Service is to allow Bluetooth accessories a simple and convenient way to send iBeacons to
iOS devices. This is a Silicon Labs Bluetooth Smart application demo implements iBeacon device which sends
non-connectible advertisements in iBeacon format.
non-connectible advertisements in ibeacon format.
🤗 SOC - Empty
Silicon Labs Bluetooth Smart application demo implementing a minimal project structure as a starting point for custom
applications. The project has the basic functionality enabling peripheral connectivity, without GATT services.
NCP - Empty target
Silicon Labs Bluetooth Smart application NCP (Network co-processor) target demo with no GATT services included.
SOC - ThunderBoard React
Silicon Labs Bluetooth Smart application for the RD-0057 ThunderBoard React
Start with a blank application
(?) < Back Next > Finish Cancel
Figure 6.8. Select ThunderBoard-React Sample Application

Select a suitable name for your project and click *Next*. In the Project Setup screen, make sure ThunderBoard-React is selected in the Board section. Once this is done, the Part section should be automatically set to EFR32BG1B232F256GM48. Then click *Finish*.

Ň

e	
Project setup	
Select the board, part, and initial build configurations.	
Boards:	C
Search	-
ThunderBoard React (RD-005701 Rev 01) ×	si Oi
Part:	
Search	Ť.
EFR32BG1B232F256GM48	
Check the configurations to include in the project	0
▲ 📝 IAR ARM (∨7.60.1.11101)	Select All
Debug (active)	
Release	Select None
	Set Active
Manage toolch	
Manage build tar	rgets
	inish Cancel
? < Back Next > Fi	inish Cancel

Figure 6.9. Project Setup with IAR ARM

Simplicity Studio will then create a project and open it in the Simplicity IDE and Configurator. In the soc-thunderboard-react.isc tab, click Generate to fully populate the project with the appropriate files and settings. Click OK to overwrite any files when prompted.


Figure 6.10. Project Generation

Once the project is generated, it can be built by going to Project->Build Project

Record

## 6.5 Program Thunderboard React

In order to program ThunderBoard-React, you need an external debugger/programmer, like a Wireless Starter Kit, a 10-pin adapter (SLSDA001A), and a10-pin ribbon cable (supplied with SLSDA001A).



Figure 6.11. Connect Simplicity Studio to a Thunderboard React via Wireless STK

Follow these steps to connect the Wireless STK as a debugger to the Thunderboard React, as shown in the picture above:

- 1. Remove the radio module plugin on the Wireless Starter Kit.
- 2. Attach 10-pin adapter board (SLSDA001A) to the two male 20-pin connectors on the Wireless STK.
- 3. Connect the 10-pin ribbon cable to the middle 10-pin connector, marked *MINI*. The key tap on the ribbon cable connector should be pointing down.
- 4. Connect the other end of the 10-pin ribbon cable to the 10-pin Mini Simplicity connector on the ThunderBoard-React
- 5. Connect the Wireless STK to the platform running Simplicity Studio via either USB or Ethernet.
- 6. Make sure the power switch on the bottom of the Wireless STK is in the rightmost position, marked AEM.
- 7. Make sure the power switch on the ThunderBoard React is in the Vext position (away from the battery holder).

In Simplicity Studio return to the main perspective, and left-click on the connected J-link device from the Device list on the left and click on *Device Configuration...* from the menu that appears.



Figure 6.12. Device Configuration

In the Configuration menu that appears, go to the Adapter Configuration tab and set Debug Mode to OUT.

J-Link Silicon Labs (440038199)	
Configuration of device: J-Link Silicon Labs (440038199)	
Device hardware Adapter Configuration J-	Link Configuration
Update Adapter Installation Package	Browse Install Package
Debug Mode: OUT 👻	Ś
	No
	, No
	×0 <sup>×</sup>
	6
	20
el	
	OK Cancel

Figure 6.13. Setting Debug Mode

In the Device hardware tab, set the Target part to EFR32BG1B232F256GM48 and set the Boards selection to ThunderBoard React (RD-005701 Rev01). This will ensure Simplicity Studio is set to communicate with ThunderBoard-React through the external adapter interface.

## UG164: Thunderboard<sup>TM</sup> React (RD-0057-0201) User's Guide Firmware

😵 J-Link Silicon Labs (440038199)	
Configuration of device: J-Link Silicon Labs (440038199)	
Device hardware Adapter Configuration J-Link Configuration	
All detected information:	0
Parts:	
Boards: Wireless Starter Kit Mainboard (BRD4001A Rev A01)	
Target part:	29
Search	0-
EFR32BG1B232F256GM48	
Target Interface: SWD -	
Boards:	
Search	-
ThunderBoard React (RD-005701 Rev 01) ×	
ОК	Cancel

Figure 6.14. Set Correct Target Part

Once the Debug connection is set up, you can choose to program the ThunderBoard-React with a pre-compiled binary from the Bluetooth Smart SDK or start a debug session from a ThunderBoard React Sensors Demo project in the Simplicity IDE (Press F11 in Simplicity IDE with ThunderBoard React project active).

To program a pre-compiled demo, select the ThunderBoard React RD-0057-0201 from the Solutions tab on the left-hand side of the main perspective where we added it earlier. Click on *Getting Started* in the main window, and click on the SOC – ThunderBoard React box in the Demos list below. In the Demos box that appears, you can select Mode to run with or without the Energy Profiler, and click *Start*. When asked to select the kit to run the demo, select the J-Link device that you configured for Debug=OUT earlier. Click *OK* and the demo should be programmed to the ThunderBoard-React.

lame	Description
SOC - ThunderBoard React Sensors	Silicon Labs Bluetooth Smart ThunderBoard R.
ilicon Labs Bluetooth Smart ThunderBoard React Se	ensors Demo for the RD-0057 ThunderBoard React
ode: Run under Energy Profiler 👻	601
Enable Code Correlation (1)	50

# Figure 6.15. Program ThunderBoard React Sample Application

You have successfully programmed a ThunderBoard-React! Note that in some cases when performing this step, the ThunderBoard-React's Si1133 power supply will drop and cause the board to flash both Blue and Green LEDs. If this occurs, remove both the cable and the coin-cell battery, and let the ThunderBoard-React sit without power for at least ten minutes. This will clear the Si1133's low supply detection circuitry.

## 6.6 Sensor and IO Firmware Handling

The following sensor data is obtained by the BMG111 module and made available via the Bluetooth Smart connection:

- · 3-axis accelerometer
- 3-axis gyroscope
- · Relative humidity
- Temperature
- · Ambient Light
- · UV index
- · Battery level
- Recommended for New Desit · Hall-effect detection

## 6.6.1 Accelerometer and Gyroscope

The accelerometer and gyroscope in the MPU-6500 is used to present acceleration and orientation of the sensor board. The orientation of the board is divided into three axes: X, Y, and Z, as shown in the figure below.



Figure 6.16. Hardware Axis Orientation

To minimize offset in the gyroscope data, the firmware supports a calibration (reset orientation) command. When a calibration is started, the sensor board must be left stationary until the calibration is complete. LED-G will be lit as long as the calibration is ongoing.

When the calibration (reset orientation) command is issued, a reference coordinate system (x, y, z in the figure below) is defined to be equal to the hardware's actual X, Y, and Z positioning. After calibration successfully completes, any change in orientation after the orientation reset will be represented in the angle difference between X, Y, and Z and x, y, and z, according to the figure below. The angles presented are Alpha ( $\alpha$ ), Beta ( $\beta$ ), and Gamma ( $\gamma$ ).



Figure 6.17. Orientation Representation

The accelerometers and gyroscope sensors are sampled at 200 Hz by the firmware and the sensor data is used to calculate acceleration and orientation, which can be sent as GATT notifications at 5 Hz.

Note that these sensors have measurement limitations, and exposing them to excessive inputs will cause measurement errors. The accelerometers has a measurement range of  $\pm 16$  g and the gyroscopes can detect maximum  $\pm 2000$  deg/s. If the user rotates the device quickly or drops it on a table, the sensors will most likely enter an overflow situation. There is no indication that an overflow has occurred.

Normally, the accelerometers are used to calculate the acceleration and the gyroscopes are used to calculate orientation. However, the combination of accelerometers and gyroscopes makes it possible to zero out drift in the x and y-axis orientations as long as the x and y-axis are within  $\pm 80^{\circ}$  or the x-axis is within  $180 \pm 80^{\circ}$  of the horizontal plane. In this case, the calculated orientation for the x and y-axis will converge towards the angles calculated from the accelerometers with a time constant of approximately five seconds. There are no adjustments for the z-axis orientation. Consequently, the calibration will reset the z-angle but not the x and y-angles. The X and Y-axis is always pointing along the horizontal plane.

There are different rotations that can put the device in a given orientation. However, the convention to bring the device back to its reference where x, y, and z are zero is to first rotate z degrees in the Z-axis, then y degrees in the Y-axis and finally x degrees in the X-axis. Because of this convention, the x and z-axis will have a range of  $\pm 180^{\circ}$  and the y-axis has a range of  $\pm 90^{\circ}$ .

A few examples can illustrate this. All rotations are done "clockwise", which is at increasing angles when started at zero. All examples should start at an orientation approximately zero degrees in all three axes.

Rotate the device  $360^{\circ}$  around the X-axis: During rotation, the x orientation will increase from 0 to  $180^{\circ}$  when the device is upside down. Then the x orientation will "jump" from 180 to -179 and continue to increase up to 0 when it is back in the start orientation.

Rotate the device  $360^{\circ}$  around the Y-axis: During rotation, the y orientation will increase from 0 to  $90^{\circ}$  when pointing downwards. Rotating it further will make the x-axis to "flip" from 0 to  $180^{\circ}$  indicating that the device is upside down and "flip" the z-axis from 0 to  $180^{\circ}$  indicating that it is pointing in the opposite direction relative to start. Rotating it further from pointing down to pointing up will decrease the y orientation from 90 to  $-90^{\circ}$ . At the top, the x and z orientation will again "flip" back to 0 and the y orientation will increase from  $-90^{\circ}$  to 0. Note that when the device is upside down, the x orientation can easily "flip" between 180 and  $-179^{\circ}$  for small rotations in the X-axis.

Rotate the device  $360^{\circ}$  around the Z-axis: During rotation, the z x orientation will increase from 0 to  $180^{\circ}$ . Then the z orientation will jump from 180 to -179 and continue to decrease down to 0 when it is back in the start position.

## 6.6.2 Environment Sensors

The Si7021 measures both relative humidity and temperature, whereas the Si1133 measures ambient light and UV index. The sensors are measured when a read command is received and the measurement data is included in the read response.

## 6.6.3 Battery Level

The battery level is sensed by the BGM111 as it measures the supply voltage level and translates this into a percentage of remaining charge using a look-up table specific for a given CR2032 battery. The battery level is measured every ten seconds.

## 6.6.4 Hall-effect Sensor

The hall-effect sensor is used to count wheel revolutions by detecting nearby magnetic fields beyond a threshold and will increment a revolution counter every time the sensor outputs a rising edge. The GATT client is notified of the updated revolution count at a 5 Hz rate through the CSC service.

## 6.7 Firmware Operation

The firmware operates as a Bluetooth Smart peripheral and has five main states.



Figure 6.18. Firmware Application State Diagram

## 6.7.1 Self-test State

After the device wakes up from Reset, it performs a Self-test to check that all sensors are can be accessed and that there are no hardware failures. If the test is OK, the device transitions to the Sleep state. If a failure is found, the device enters the Error state.

#### 6.7.2 Error State

If an error is found, the device stays in the Error state until the device is reset by removing and re-installing the battery. While in this state, the blue LED (LED-B) and green LED (LED-G) will blink in an alternating pattern.

#### 6.7.3 Sleep State

In this state the Bluetooth Smart stack is not operational, all sensors are put in their lowest power state and the BGM111 is put in a Deep Sleep state (EM2). The current consumption in this state is around 10  $\mu$ A. While in this state, both the blue and green LEDs are extinguished.

#### 6.7.4 Advertisement State

In this state, the Bluetooth Smart stack is in Advertising mode using the data found in Table 6.1 Beacon Advertisement Data on page 45. All sensors are put in their lowest power state and the BGM111 is in Sleep (EM1) between each advertisement transmission. If a connection is made to a central device, the advertisement is stopped and the device enters the Connected state. If no connection is made within 30 seconds, the device goes back to the Deep Sleep state. While in Deep Sleep state, the blue LED (LED-B) is blinking once a second and the green LED (LED-G) is off.

## 6.7.5 Connected State

This state is entered once a device is connected to a central device. In this state, the device acts as a GATT server and all sensors are configured to their respective operational states. The BGM111 is in Sleep (EM1) when not handling the stack or the sensors.

- The green LED (LED-G) blinks once when a connection is opened.
- Both LEDs can be set/cleared by the central device (GATT client) through the Bluetooth Smart connection (Automation IO service).

## 6.8 Bluetooth Smart Over-the-air Definition

This section describes the over-the-air interface between the phone application and the Thunderboard React including advertisement data, scan response, and GATT services and characteristics.

## 6.8.1 Advertisement

The EFR32 Blue Gecko alternates between two advertisement payloads every second. One payload is an iBeacon payload and the other is a regular non-beacon payload containing the local name and a manufacturing-specific firmware ID.

## 6.8.2 iBeacon Advertisement Payload

Below is the advertisement payload sent out by the BGM111 in an uni-directed connectable mode. It implements an Apple iBeacon format and advertises on all advertisement channels.

Туре	Value	Description
UINT8	0x02	FLAGS_LENGTH
UINT8	0x01	FLAGS_TYPE
UINT8	0x05	FLAGS_BREDR_NOT_SUPPORTED
		FLAGS_LIMITED_DISCOVERABLE
UINT8	0x1A	MANDATA_LENGTH
UINT8	0xFF	MANDATA_TYPE
UINT16	0x004C	MANDATA_BEACON_COMPANYID
UINT16	0x1502	MANDATA_BEACON_TYPE
UINT128	0xCEF797DA-2E91-4EA4-A424-F45082AC0682	MANDATA_BEACON_UUID
UINT16	0x00nn	MANDATA_BEACON_MAJOR
UINT16	0xnnnn	MANDATA_BEACON_MINOR
UINT8	0xC3	MANDATA_BEACON_RSSI

## Table 6.1. Beacon Advertisement Data

The major and minor values of the beacon payload together constitute a 24-bit ID that is unique to an individual ThunderBoard device. The two Least Significant Octets of the unique ID equals the 16-bit minor value. The Most Significant Octet of the unique ID equals the table above. The unique ID is equal to the #nnnnnnn decimal value given in the Device Name in the table above. The unique ID is also equal to the three Least Significant Octets of the Manufacturer Identifier in 6.9.3 Device Information Service (0x180A).

silabs.com | Smart. Connected. Energy-friendly.

## 6.8.3 Non-beacon Advertisement Payload

Below is the non-beacon advertisement payload sent by the BGM111 on all advertisement channels.

## Table 6.2. Non-beacon Advertisement Payload

Туре	Value	Description
UINT8	0x02	FLAGS_LENGTH
UINT8	0x01	FLAGS_TYPE
UINT8	0x05	FLAGS_BREDR_NOT_SUPPORTED
		FLAGS_LIMITED_DISCOVERABLE
UINT8	0x06	MANDATA_LEN
UINT8	0xFF	MANDATA_TYPE
UINT16	0x0047	MANDATA_COMPANY_ID
UINT16	0x0001	MANDATA_FIRMWARE_ID
UINT8	Length of local name +1	LOCALNAME_LENGTH
UINT8	0x09	LOCALNAME_TYPE
UINT8[n]	Local name	LOCALNAME

The MANDATA\_FIRMWARE\_IDE field can be used to uniquely identify the capabilities of the board firmware.

Local name is the same as "Device Name" in the Generic Access Service. If the "Device Name" is changed, the Local name will be changed accordingly.

## 6.9 GATT Description

## 6.9.1 Generic Access Service (0x1800)

Characteristic			Interpretation	Droportion	Descriptor
Characteristic	UUID	Byte	Encoding	<ul> <li>Properties</li> </ul>	Descriptors
Device Name	0x2a00		UFT8S	Read Write <sup>1</sup>	
			"Thunder React #nnnnn"		
			nnnnn is a 5-decimal digit serial		
Appearance	0x2a01	0:1	UINT16	Read	
			0: Unknown		
ote:	1			1	1

## Table 6.3. Characteristics included in Generic Access Service

## 6.9.2 Generic Attribute Service (0x1801)

Table 6.4. Characte	ristics Included in	n Generic Attribute S	ervice
---------------------	---------------------	-----------------------	--------

Characteristic	UUID		Interpretation	Properties	Descriptors
		Byte	Encoding		C
Service Changed	0x2a05	0:1	UINT16	Indicate	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
			Start of affected attribute handle range		
		2:3	UINT16		
			End of affected attribute handle range		S

The Service Changed Attribute is included to avoid caching of the device name in iOS devices.

## 6.9.3 Device Information Service (0x180A)

# Table 6.5. Characteristics included in Device Information Service

Characteristic	UUID		Interpretation	Properties	Descriptors
Characteristic	0010	Byte	Encoding	Fropenties	Descriptors
Manufacturer Name String	0x2a29		UFT8S "Silicon Labs"	Read	
Model Number String	0x2a24		UTF8S "RD-0057"	Read	
Hardware Revision String	0x2a27		UTF8S 4 digit string	Read	
Firmware Revision String	0x2a26		UTF8S X.Y.Z revision format	Read	
System ID	0x2a23	0:4	UINT40 Manufacturer Identifier UINT24	Read	
			Organizationally Unique Identifier		

# 6.9.4 Battery Service (0x180f)

## Table 6.6. Characteristics included in Battery Service

Characteristic		UUID	Interpretation		Properties	Descriptors	
		UUID	Byte	Encoding	Froperties	Descriptors	
	Battery Level	0x2a19	0	UINT8: Battery level in %	Read Notify	Client Characteristic	
						Configuration	

## 6.9.5 Environmental Sensing Service (0x181a)

# Table 6.7. Characteristics included in Environmental Sensing Service

Characteristic	UUID	Interpretation		Properties	Descriptors	
Characteristic	0010	Byte Encoding		Fropenties	Descriptors	
Humidity	0x2a6f	0:1	UINT16	Read		
			Unit in % with resolution of 0.01 %			
Temperature	0x2a6e	0:1	INT16	Read	29	
			Units in °C with resolution of 0.01 °C		5	
UV Index	0x2a76	0	UINT8	Read	5	
			Unit-less			

## 6.9.6 Ambient Light Service (0xd24c4f4e-17a7-4548-852c-abf51127368b)

# Table 6.8. Characteristics included in Ambient Light Service

Characteristic	UUID		Interpretation	Properties	Descriptors	
Characteristic		Byte Encoding		Properties	Descriptors	
Ambient Light	0xc8546913- bfd9-45eb-8dde-9f8 754f4a32e	0:3	UINT32 Lux with resolution of 0.01 lux	Read		
Noir	South	ner				

## 6.9.7 Cycling Speed and Cadence Service (0x1816)

Characteristic	UUID		Interpretation	Properties	Descriptors
Gilaracteristic	OOD	Byte	Encoding	Fiopenies	Descriptors
CSC Measurement	0x2a5b	0	Bit 0: Wheel Revolution Data Present	Notify	Client Characteristic
			(1 = True)		Configuration
		1:4	UINT32		
			Cumulative Wheel Revolutions		S
		5:6	UINT16: Last Wheel Event Time given with a resolution of 1/1024 s.		6
CSC Feature	0x2a5c	0:1	Bit 0: Wheel Revolution Data Supported	Read	
			(1 = True)		
SC Control Point	0x2a55	0	UINT8	Write	Client Characteristic
			Op Code	Indicate	Configuration
			0x01: Set Cumulative Value		
		1:4	UINT32		
			Cumulative Value		
		5	UINT8		
			Request Op Code		
			0x01: Set Cumulative Value		
		6	UINT8		
			Response Value		
			0x01: Success		
			0x02: Not supported		
Joi R			0x03: Invalid parameter		
			0x04: Operation Failed		

## 6.9.8 Acceleration and Orientation Service (0xa4e649f4-4be5-11e5-885d-feff819cdc9f)

Characteristic	UUID	Interpretation		Properties	Descriptors
		Byte	Encoding	Topenies	Descriptors
Acceleration Measurement	0xc4c1f6e2-4be5-1 1e5-885d-	0:1	INT16: Acceleration along X-axis. Units in g with resolution of 0.001 g	Notify	Client Characteristi Configuration
Wedearennent	feff819cdc9f	2:3	INT16: Acceleration along Y-axis. Units in g with resolution of 0.001 g		
		4:5	INT16: Acceleration along Z-axis. Units in g with resolution of 0.001 g		0,5
Orientation Measurement	0xb7c4b694- bee3-45dd-ba9f- f3b5e994f49a	0:1	INT16: Orientation alpha angle in deg (+180 to –180) with resolution of 0.01°	Notify	Client Characteristi Configuration
		2:3	INT16: Orientation beta angle in deg (+90 to –90) with resolution of 0.01°	NS	
		4:5	INT16: Orientation gamma angle in deg (+180 to –180) with resolution of 0.01°		
Control Point	0x71e30b8c-4131- 4703-b0a0-	0	UINT8	Write	Client Characteristi Configuration
	b0bbba75856b		Op Code	Indicate	Computation
			0x01: Start calibration		
			0x02: Reset orientation		
			0x10: Response Code		
		1	UINT8		
		$\overline{0}$	Request Op Code		
			Only used in response		
		2	UINT8		
			Response Value		
			0x01: Success		
			0x02: Error		

# Table 6.10. Characteristics included in Acceleration and Orientation Service

## 6.9.9 Automation IO Service (0x1815)

Characteristic	UUID		Interpretation	Properties	Descriptors
		Byte	Encoding		
Digital (Input or output type can be read from the Characteristic Presen- tation Format descrip- tor.)	0x2a56	0	Array of 2 2-bit values Each 2 bit values correspond to the state of an IO: 0b00 = Inactive state 0b01 = Active state 0b10 = Tristate state 0b11 = Unknown state The least significant 2-bit value corre- sponds to digital IO 0.	Read Notify	Client Characteristic Configuration, Characteristic Presen- tation Format, Number of digitals
Digital (Input or output type can be read from the Characteristic Presen- tation Format descrip- tor.)	0x2a56	0	Array of 2 2-bit values Each 2 bit values correspond to the state of an IO: 0b00 = Inactive state 0b01 = Active state 0b10 = Tristate state 0b11 = Unknown state The least significant 2-bit value corre- sponds to digital IO 0.	Read Write	Characteristic Presen- tation Format, Number of digitals

## Table 6.11. Characteristics Included in Automation IO Service

The les

Descriptor	UUID	Interpretation		Properties	
		Byte Encoding			
Characteristic	0x2904	0	0 Digital IO Format		
Presentation Format			UINT8		
			Value = 27: Opaque Struct		
		1	Exponent		
			INT8	5	
			Value = 0	5	
		2:3	Unit		
			UINT16:		
			Value = 0x2700 (Unit-less)		
		4	Namespace		
			UINT8		
			Value = 1 (Bluetooth SIG Assigned Numbers)		
		5:6	Description		
			UINT16		
			Value = 1: Digital input		
			Value = 2: Digital output		
Number of digitals	0x2909		Number of digital IOs represented by this characteristic	Read	
			UINT8		
		0	Value = 2		

## Table 6.12. Descriptors Included in Characteristics for Automation IO Service

	.on
Re	
4°t	

# 7. Software

This section describes how to obtain the mobile app and cloud software. Each application also includes a readme.md that provides an overview and how to make use of the source code if one wants to modify the particular application.

## Android Mobile App

Recommended to Membesil The android mobile app source code can be found here:

https://github.com/SiliconLabs/thunderboard-android

## **iOS Mobile App**

The iOS mobile app source code can be found here:

https://github.com/SiliconLabs/thunderboard-ios

## ThunderCloud

The cloud platform's source code can be found here:

https://github.com/SiliconLabs/thundercloud



#### Disclaimer

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice and limitation to product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Silicon Labs shall have no liability for the consequences of use of the information supplied herein. This document does not imply or express copyright licenses granted hereunder to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any Life Support System without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons.

#### **Trademark Information**

Silicon Laboratories Inc.®, Silicon Laboratories®, Silicon Labs®, SiLabs® and the Silicon Labs logo®, Bluegiga®, Bluegiga®, Bluegiga®, Clockbuilder®, CMEMS®, DSPLL®, EFM®, EFM32©, EFR, Ember®, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember®, EZLink®, EZRadio®, EZRadio®, EZRadioPRO®, Gecko®, ISOmodem®, Precision32®, ProSLIC®, Simplicity Studio®, SiPHY®, Telegesis, the Telegesis Logo®, USBXpress® and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 USA

# http://www.silabs.com



Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию.

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России, а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научноисследовательскими институтами России.

С нами вы становитесь еще успешнее!

## Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург, Промышленная ул, дом № 19, литера Н, помещение 100-Н Офис 331