


**Future  
Technology  
Devices  
International Ltd  
UMFT602A/  
UMFT602X**



The UMFT602A/X is an evaluation/development module with either HSMC or FMC (LPC) connectors for interfacing FTDI's FT602 32bit FIFO bus to USB 3.1 GEN 1 USB video class (UVC) bridge IC with external hardware. The UMFT602A/X allows for bridging a FIFO bus to a USB3.0 host and evaluating the functionality of the FT602.

As a daughter card, the UMFT602A/X must work with a FIFO master board which has either a HSMC or FMC connector. There are 2 models which provide different FIFO bus interfaces with 32bit data width.

The modules are designed such that they can plug into most FPGA development platforms supplied by vendors such as Xilinx or Altera. Refer to [Ordering Information](#) for module options.

The UMFT602A/X supports 2 parallel slave FIFO bus protocols (Multi-Channel FIFO / 245 Synchronous FIFO) with a data "burst" rate of up to 400MB/s. For a full list of the FT602's features refer to the [FT602 datasheet](#).

The UMFT602A/X module has the following features:

- Supports USB 3.1 GEN 1 Super Speed (5Gbps)/USB 2.0 High Speed (480Mbps) transfer
- UVC 1.1, Raw YUV422, support 14 UVC resolutions
- Up to 4 video input channels. One I2C bus master interface for video source device configuration
- Supports multi voltage I/O: 1.8V, 2.5V and 3.3V
- High speed connector for FIFO bus : FMC(Field Programmable Mezzanine Card) or HSMC (High Speed Mezzanine Card)
- FMC connector is compatible with most Xilinx FPGA reference design boards
- HSMC is compatible with most Altera FPGA reference design boards
- Multi powered options: external DC powered, BUS powered, FMC/HSMC powered
- Hardware Reset
- Micro-USB3.0 receptacle, USB3.0 compliant and certified

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. Future Technology Devices International Ltd will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH United Kingdom. Scotland Registered Company Number: SC136640

## 1 Ordering Information


| Part No.   | Description                                   |
|------------|---|
| UMFT602A-B | 32 Bit FIFO bus, HSMC connector               |
| UMFT602X-B | 32 Bit FIFO bus, FMC(Low Pin Count) connector |

**Table 1.1 UMFT60xx Ordering Information**


## **Table of Contents**

|  |  |           |
|--|--|-----------|
| <b>1</b>   | <b>Ordering Information .....</b>                          | <b>2</b>  |
| <b>2</b>   | <b>Hardware Description .....</b>                          | <b>4</b>  |
| <b>2.1</b>   | <b>Physical Description .....</b>                          | <b>5</b>  |
| 2.1.1  | Dimensions .....   | 5         |
| <b>2.2</b>   | <b>Connectors, Jumpers and Push Buttons .....</b>          | <b>7</b>  |
| 2.2.1  | CN1 - Micro USB3.0 Receptacle .....                        | 7         |
| 2.2.2  | CN2 - POWER JACK 2.1MM .....                               | 7         |
| 2.2.3  | JP1 - External/VBUS Powered Selection .....                | 7         |
| 2.2.4  | JP2 - VCC33 Selection .....                                | 8         |
| 2.2.5  | JP3, JP6- VCCIO Selection .....                            | 8         |
| 2.2.6  | SW1, SW2 - Push Buttons for Reset and Remote Wake Up ..... | 8         |
| 2.2.7  | CN4 - FMC / HSMC FIFO bus interface connector .....        | 8         |
| <b>3</b>   | <b>Board Schematics .....</b>                              | <b>13</b> |
| <b>4</b>   | <b>Hardware Setup Guide .....</b>                          | <b>17</b> |
| <b>4.1</b>   | <b>Power Configuration .....</b>                           | <b>17</b> |
| <b>4.2</b>   | <b>Jumpers Default Position .....</b>                      | <b>17</b> |
| <b>4.3</b>   | <b>Power Consumption .....</b>                             | <b>18</b> |
| <b>5</b>   | <b>Contact Information .....</b>                           | <b>19</b> |
| <b>Appendix A – References .....</b>                   |  | <b>20</b> |
| Document References .....                              |  | 20        |
| Acronyms and Abbreviations .....                       |  | 20        |
| <b>Appendix B – List of Tables &amp; Figures .....</b> |  | <b>21</b> |
| List of Tables .....                                   |  | 21        |
| List of Figures .....                                  |  | 21        |
| <b>Appendix C – Revision History .....</b>             |  | <b>22</b> |

## 2 Hardware Description



**Figure 2-1 UMFT602A Module Top and Bottom View**



**Figure 2-2 UMFT602X Module Top and Bottom View**


The main functions of the UMFT602A/X module are as follows:

- Provides Multi-channel FIFO mode and 245 Synchronous FIFO mode Protocols.
- YUV422 uncompressed format is supported.
- FIFO clock: 100MHz, driven by FT602.
- High speed FIFO bus interface: FMC (Low Pin Count) and HSMC optional. See [Ordering Information](#).
- Jumper's selection allowing powered options: VBUS-powered, External DC-powered, FIFO master board-powered.
- Multi voltage VCCIO option: 1.8V, 2.5V, 3.3V, default is 2.5V.
- Hardware reset and System wake up.

## 2.1 Physical Description

The UMFT602A and UMFT602X modules dimensions are illustrated in Figure 2.5 to Figure 2.8.

### 2.1.1 Dimensions




**Figure 2-3 UMFT602A Dimensions (Top view)**




**Figure 2-4 UMFT602A Dimensions (Side view)**

±0.10mm Tolerance



**Figure 2-5 UMFT602X Dimensions (Top view)**



**Figure 2-6 UMFT602X Dimensions (Side view)**

±0.10mm Tolerance

## 2.2 Connectors, Jumpers and Push Buttons

Connectors, jumpers and push buttons are described in the following sections.

### 2.2.1 CN1 - Micro USB3.0 Receptacle

| Pin No. | Name  | Type | Description                                       |
|---------|-------|------|---|
| 1       | VBUS  | P    | 5V DC power supply                                |
| 2       | D-    | IO   | USB D- line                                       |
| 3       | D+    | IO   | USB D+ line                                       |
| 4       | ID    | IO   | OTG identification(N.C.)                          |
| 5       | GND   | P    | Ground  |
| 6       | SSTX- | O    | Super Speed USB transmitter differential pair (-) |
| 7       | SSTX+ | O    | Super Speed USB transmitter differential pair(+)  |
| 8       | GND   | P    | Ground  |
| 9       | SSRX- | I    | Super Speed USB receiver differential pair (-)    |
| 10      | SSRX+ | I    | Super Speed USB receiver differential pair (+)    |

**Table 2.1 CN1 - Micro USB3.0 Pin-out**

### 2.2.2 CN2 – POWER JACK 2.1MM

Optional external DC 5V input.

| Pin No. | Name | Type | Description     |
|---------|------|------|-----------------|
| 1       | 5V   | P    | 5V power supply |
| 2       | GND  | P    | Ground          |
| 3       | GND  | P    | Ground          |

**Table 2.2 CN2 – POWER JACK 2.1MM**

### 2.2.3 JP1 – External/VBUS Powered Selection

Select whether the module power is supplied by an external DC 5V or VBUS. Note this setting must be chosen in conjunction with the JP2 setting. Default is open. <sup>[Note]</sup>

| Jumper position | Description           |
|-----------------|-----------------------|
| Short pin 1-2   | Select VBUS Power     |
| Short pin 2-3   | Select external DV 5V |

**Table 2.3 JP1 – 5V input Options**

### 2.2.4 JP2 – VCC33 Selection

Select whether the module main power is supplied by DC5V or the FIFO master board DC3.3V.<sup>[Note]</sup>

| Jumper position | Description                                  |
|-----------------|--|
| Short pin 1-2   | Select powered by external DV5V or VBUS      |
| Short pin 2-3   | Select powered by FIFO master Board(default) |

**Table 2.4 JP3 – VCC33 Option**

### 2.2.5 JP3, JP6– VCCIO Selection

Select the IO voltage level. <sup>[Note]</sup>

| Jumper position |       | Description         |
|-----------------|-------|---------------------|
| JP3             | JP6   |                     |
| Short pin 1-2   | Open  | VCCIO=2.5V(default) |
| Short pin 2-3   | Open  | VCCIO=1.8V          |
| Open            | Short | VCCIO=3.3V          |

**Table 2.5 JP3 – VCCIO Option**

**Note:** Refer to section [4 Hardware setup guide](#) for more details on power configuration options and jumpers positions.

JP6 is not fitted on the PCB.

### 2.2.6 SW1, SW2 – Push Buttons for Reset and Remote Wake Up

SW1 – Reset, module hardware reset, mapped to FMC/HSMC connector, can be used for FIFO master reset. Drive low when press down.

SW2 – FT602 device Wake Up, driven low when pressed down. This pin mapped is to the FMC/HSMC connector, and is normally used for I<sup>2</sup>C interrupt.

### 2.2.7 CN4 – FMC / HSMC FIFO bus interface connector

#### 2.2.7.1 FMC connector configurations- UMFT602X Module

| FMC Pin#/Name | UMFT602X<br>U1: FT602 Pin#/Name |
|---------------|---------------------------------|
| C14/LA10_P    | 16 /INT_N/Wake Up_N             |
| C15/LA10_N    | 15 /RESET_N                     |
| C18/LA14_P    | 17 /I2C_SCL                     |
| C19/LA14_N    | 18 /I2C_SDA                     |



| <b>FMC Pin#/Name</b> | <b>UMFT602X<br/>U1: FT602 Pin#/Name</b> |
|----------------------|---|
| C22/LA18_P_CC        | 68 /D_CLK (FIFO bus clock,FT602 output) |
| C26/LA27_P           | 62 /DATA18                              |
| C27_LA27_N           | 60 /DATA16                              |
| D14/LA09_P           | 8 /BE_N_3                               |
| D15/LA09_N           | 7 /BE_N_2                               |
| D20/LA17_P_CC        | 76 /DATA31                              |
| D21/LA17_N_CC        | 75 /DATA30                              |
| D23/LA23_P           | 70 /DATA25                              |
| D24/LA23_N           | 69 /DATA24                              |
| D26/LA26_P           | 63 /DATA19                              |
| D27/LA26_N           | 61 /DATA17                              |
| G6/LA00_P_CC         | 13 /RESERVE3                            |
| G7/LA00_N_CC         | 12 /RESERVE2                            |
| G12/LA08_P           | 11 /WR_N                                |
| G13/LA08_N           | 10 /RESERVE1                            |
| G21/LA20_P           | 74 /DATA29                              |
| G22/LA20_N           | 73 /DATA28                              |
| G24/LA22_P           | 67 /DATA23                              |
| G25/_LA22_N          | 65 /DATA21                              |
| G27/LA25_P           | 57 /DATA15                              |
| G28/LA25_N           | 55 /DATA13                              |
| G30/LA29_P           | 53 /DATA11                              |
| G31/LA29_N           | 51 /DATA9                               |
| G33/LA31_P           | 47 /DATA7                               |
| G34/LA31_N           | 45 /DATA5                               |
| G36/LA33_P           | 43 /DATA3                               |
| G37/LA33_N           | 41 /DATA1                               |
| H13/LA07_P           | 9 /RXF_N                                |

| <b>FMC Pin#/Name</b> | <b>UMFT602X<br/>U1: FT602 Pin#/Name</b> |
|----------------------|---|
| H14/LA07_N           | 8 /TXE_N                                |
| H19/LA15_P           | 5 /BE_N_1                               |
| H20/LA15_N           | 4 /BE_N_0                               |
| H22/LA19_P           | 72 /DATA27                              |
| H23/LA19_N           | 71 /DATA26                              |
| H25/LA21_P           | 66 /DATA22                              |
| H26/LA21_N           | 64 /DATA20                              |
| H28/LA24_P           | 56 /DATA14                              |
| H29/LA24_N           | 54 /DATA12                              |
| H31/LA28_P           | 52 /DATA10                              |
| H32/LA28_N           | 50 /DATA8                               |
| H34/LA30_P           | 46 /DATA6                               |
| H35/LA30_N           | 44 /DATA4                               |
| H37/LA32_P           | 42 /DATA2                               |
| H38/LA32_N           | 40 /DATA0                               |

**Table 2.6 CN4 – FMC connector configuration for FIFO bus**

### 2.2.7.2 CN4 – HSMC connector configurations-UMFT602A Module

| <b>HSMC<br/>Pin#/Name</b> | <b>UMFT602A<br/>U1: FT602 Pin#/Name</b> |
|---------------------------|---|
| 40 /CLKIN0                | 68 /D_CLK (FIFO bus clock,FT602 output) |
| 41 /D0                    | 40 /DATA0                               |
| 42 /D1                    | 60 /DATA16                              |
| 43 /D2                    | 41 /DATA1                               |
| 44 /D3                    | 61 /DATA17                              |
| 47 /D4                    | 42 /DATA2                               |
| 48 /D5                    | 62 /DATA18                              |
| 49 /D6                    | 43 /DATA3                               |

| <b>HSMC<br/>Pin#/Name</b> | <b>UMFT602A<br/>U1: FT602 Pin#/Name</b> |
|---------------------------|---|
| 50 /D7                    | 63 /DATA19                              |
| 53 /D8                    | 44 /DATA4                               |
| 54 /D9                    | 64 /DATA20                              |
| 55 /D10                   | 45 /DATA5                               |
| 56 /D11                   | 65 /DATA21                              |
| 59 /D12                   | 46 /DATA6                               |
| 60 /D13                   | 66 /DATA22                              |
| 61 /D14                   | 47 /DATA7                               |
| 62 /D15                   | 67 /DATA23                              |
| 65 /D16                   | 50 /DATA8                               |
| 66 /D17                   | 69 /DATA24                              |
| 67 /D18                   | 51 /DATA9                               |
| 68 /D19                   | 70 /DATA25                              |
| 71 /D20                   | 52 /DATA10                              |
| 72 /D21                   | 71 /DATA26                              |
| 73 /D22                   | 53 /DATA11                              |
| 74 /D23                   | 72 /DATA27                              |
| 77 /D24                   | 54 /DATA12                              |
| 78 /D25                   | 73 /DATA28                              |
| 79 /D26                   | 55 /DATA13                              |
| 80 /D27                   | 74 /DATA29                              |
| 83 /D28                   | 56 /DATA14                              |
| 84 /D29                   | 75 /DATA30                              |
| 85 /D30                   | 57 /DATA15                              |
| 86 /D31                   | 76 /DATA31                              |
| 101 /D40                  | 4 /BE_N_0                               |
| 102 /D41                  | 8 /TXE_N                                |
| 103 /D42                  | 5 /BE_N_1                               |


| <b>HSMC<br/>Pin#/Name</b> | <b>UMFT602A<br/>U1: FT602 Pin#/Name</b> |
|---------------------------|---|
| 104 /D43                  | 9 /RXF_N                                |
| 107 /D44                  | 7 /BE_N_2                               |
| 108 /D45                  | 10 /RESERVE1                            |
| 109 /D46                  | 8 /BE_N_3                               |
| 110 /D47                  | 11 /WR_N                                |
| 113 /D48                  | 18 /I2C_SDA                             |
| 114 /D49                  | 12 /RESERVE2                            |
| 115 /D50                  | 17 /I2C_SCL                             |
| 116 /D51                  | 13 /RESERVE3                            |
| 119 /D52                  | 15 /RESET_N                             |
| 121 /D54                  | 16 / INT_N/Wake up_N                    |

**Table 2.7 CN4 – HSMC connector configuration for FIFO bus**


**Note:** Refer to the [FT602 device datasheet](#) section 3 for details of the device pin out and signal descriptions.

The reserved pins (Pin10, Pin12, and Pin13) are connected to the FIFO master via the FMC/HSMC connector, the FIFO master IOs whose connect to these pins should be configured to pull up in the normal operation.


### 3 Board Schematics




**Figure 3-1 Schematics: Power Supply for UMFT602A/UMFT602X**



**Figure 3-2 Schematics: FIFO TO USB3.0 UVC Bridge\_UMFT602A/UMFT602X**



**Figure 3-3 Schematics: HSMC\_UMFT602A**



**Figure 3-4 Schematics: FMC\_UMFT602X**



## 4 Hardware Setup Guide

### 4.1 Power Configuration

There are 3 methods of powering the UMFT602A/UMFT602X module.

- 1) FIFO master board Power (3.3V)-Connect the UMFT602A/UMFT602X board to the FIFO master board that has the standard configuration HSMC female or FMC (LPC or HPC) connector. This method is the default setting and is recommended.
- 2) USB Power (5V) - Connect USB power by micro-USB3.0 or micro-USB2.0 cable to CN1.
- 3) DC IN (5V) - Connect DC 5V to CN2.

The following table summarizes how to power the UMFT60xx module using the various methods.

| Power Method                                     | CN1 | CN2  | JP1          | JP2           | JP3 and JP6  |
|--|-----|------|--------------|---------------|--|
| FIFO master board Power(Default and Recommended) | -   | N.C. | Open         | Short pin 2-3 | Follow FIFO master IO voltage.<br>Default:<br>JP3 short pin1-2<br>VCCIO=2.5V |
| USB Power  | 5V  | N.C. | Short pin1-2 | Short pin1-2  |  |
| DC IN(5V)  | -   | 5V   | Short pin2-3 | Short pin1-2  |  |


**Table 4.1 Board Power Configuration**

### 4.2 Jumpers Default Position

| Jumper           | JP1  | JP2 | JP3 |
|------------------|------|-----|-----|
| Default Position | Open | 2-3 | 1-2 |

**Table 4.2 Jumpers Default Position**

Figure 4.1 shows the Jumpers' locations on the PCBs.



**Figure 4-1 Jumpers Locations**

### 4.3 Power Consumption

| Parameter          | Description                  | Minimum | Typical | Maximum | Units | Conditions                                     |
|--------------------|------------------------------|---------|---------|---------|-------|--|
| I <sub>VCC_1</sub> | VCC Operating Supply Current | -       | 195     | -       | mA    | Function Mode                                  |
| I <sub>VCC_2</sub> | VCC Operating Supply Current | -       | 7.0     | -       | mA    | Suspend Mode                                   |
| I <sub>VBUS1</sub> | VBUS Operating Current       | -       | 0.34    | -       | mA    | DC/HSMC/FMC Powered, Function and Suspend Mode |
| I <sub>VBUS2</sub> | VBUS Operating Current       | -       | 191     | -       | mA    | VBUS-Powered Powered, Function Mode            |
| I <sub>VBUS3</sub> | VBUS Operating Current       | -       | 7.3     | -       | mA    | VBUS-Powered Powered, Suspend Mode             |

**Table 4.3 Power Consumption**

## 5 Contact Information

### Head Office – Glasgow, UK

Future Technology Devices International Limited  
Unit 1, 2 Seaward Place, Centurion Business Park  
Glasgow G41 1HH  
United Kingdom  
Tel: +44 (0) 141 429 2777  
Fax: +44 (0) 141 429 2758

E-mail (Sales) [sales1@ftdichip.com](mailto:sales1@ftdichip.com)  
E-mail (Support) [support1@ftdichip.com](mailto:support1@ftdichip.com)  
E-mail (General Enquiries) [admin1@ftdichip.com](mailto:admin1@ftdichip.com)

### Branch Office – Tigard, Oregon, USA

Future Technology Devices International Limited  
(USA)  
7130 SW Fir Loop  
Tigard, OR 97223-8160  
USA  
Tel: +1 (503) 547 0988  
Fax: +1 (503) 547 0987

E-Mail (Sales) [us.sales@ftdichip.com](mailto:us.sales@ftdichip.com)  
E-Mail (Support) [us.support@ftdichip.com](mailto:us.support@ftdichip.com)  
E-Mail (General Enquiries) [us.admin@ftdichip.com](mailto:us.admin@ftdichip.com)

### Branch Office – Taipei, Taiwan

Future Technology Devices International Limited  
(Taiwan)  
2F, No. 516, Sec. 1, NeiHu Road  
Taipei 114  
Taiwan, R.O.C.  
Tel: +886 (0) 2 8797 1330  
Fax: +886 (0) 2 8751 9737

E-mail (Sales) [tw.sales1@ftdichip.com](mailto:tw.sales1@ftdichip.com)  
E-mail (Support) [tw.support1@ftdichip.com](mailto:tw.support1@ftdichip.com)  
E-mail (General Enquiries) [tw.admin1@ftdichip.com](mailto:tw.admin1@ftdichip.com)

### Branch Office – Shanghai, China

Future Technology Devices International Limited  
(China)  
Room 1103, No. 666 West Huaihai Road,  
Shanghai, 200052  
China  
Tel: +86 21 62351596  
Fax: +86 21 62351595

E-mail (Sales) [cn.sales@ftdichip.com](mailto:cn.sales@ftdichip.com)  
E-mail (Support) [cn.support@ftdichip.com](mailto:cn.support@ftdichip.com)  
E-mail (General Enquiries) [cn.admin@ftdichip.com](mailto:cn.admin@ftdichip.com)

### Web Site

<http://ftdichip.com>

### Distributor and Sales Representatives

Please visit the Sales Network page of the [FTDI Web site](#) for the contact details of our distributor(s) and sales representative(s) in your country.

System and equipment manufacturers and designers are responsible to ensure that their systems, and any Future Technology Devices International Ltd (FTDI) devices incorporated in their systems, meet all applicable safety, regulatory and system-level performance requirements. All application-related information in this document (including application descriptions, suggested FTDI devices and other materials) is provided for reference only. While FTDI has taken care to assure it is accurate, this information is subject to customer confirmation, and FTDI disclaims all liability for system designs and for any applications assistance provided by FTDI. Use of FTDI devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold harmless FTDI from any and all damages, claims, suits or expense resulting from such use. This document is subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Neither the whole nor any part of the information contained in, or the product described in this document, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH, United Kingdom. Scotland Registered Company Number: SC136640

## Appendix A – References

### Document References

FT602 datasheet: [DS\\_FT602Q](#)

FT60X PCB Layout Guidelines: [AN\\_430\\_FT60X\\_PCB\\_Layout\\_Guidelines](#)

[FT602\\_Chip\\_Configuration\\_Utility](#)

### Acronyms and Abbreviations

| Terms | Description                       |
|-------|-----------------------------------|
| FIFO  | First In First Out                |
| FMC   | Field Programmable Mezzanine Card |
| HPC   | High Pin Count                    |
| HSMC  | High Speed Mezzanine Card         |
| IO    | Input Output                      |
| LPC   | Low Pin Count                     |
| USB   | Universal Serial Bus              |

## Appendix B – List of Tables & Figures

### List of Tables

|   |    |
|---|----|
| Table 1.1 UMFT60xx Ordering Information .....                   | 2  |
| Table 2.1 CN1 - Micro USB3.0 Pin-out.....                       | 7  |
| Table 2.2 CN2 – POWER JACK 2.1MM .....                          | 7  |
| Table 2.3 JP1 – 5V input Options .....                          | 7  |
| Table 2.4 JP3 – VCC33 Option .....                              | 8  |
| Table 2.5 JP3 – VCCIO Option.....                               | 8  |
| Table 2.6 CN4 – FMC connector configuration for FIFO bus.....   | 10 |
| Table 2.7 CN4 – HSMC connector configuration for FIFO bus ..... | 12 |
| Table 4.1 Board Power Configuration .....                       | 17 |
| Table 4.2 Jumpers Default Position.....                         | 17 |
| Table 4.3 Power Consumption .....                               | 18 |

### List of Figures

|  |    |
|--|----|
| Figure 2-1 UMFT602A Module Top and Bottom View .....                     | 4  |
| Figure 2-2 UMFT602X Module Top and Bottom View .....                     | 4  |
| Figure 2-3 UMFT602A Dimensions (Top view) .....                          | 5  |
| Figure 2-4 UMFT602A Dimensions (Side view) .....                         | 5  |
| Figure 2-5 UMFT602X Dimensions (Top view) .....                          | 6  |
| Figure 2-6 UMFT602X Dimensions (Side view) .....                         | 6  |
| Figure 3-1 Schematics: Power Supply for UMFT602A/UMFT602X .....          | 13 |
| Figure 3-2 Schematics: FIFO TO USB3.0 UVC Bridge_UMFT602A/UMFT602X ..... | 14 |
| Figure 3-3 Schematics: HSMC_UMFT602A.....                                | 15 |
| Figure 3-4 Schematics: FMC_UMFT602X .....                                | 16 |
| Figure 4-1 Jumpers Locations .....                                       | 18 |

## Appendix C – Revision History

Document Title: UMFT602X Module Datasheet  
Document Reference No.: FT\_001390  
Clearance No.: FTDI#518  
Product Page: <http://www.ftdichip.com/Products/Modules/>  
Document Feedback: [Send Feedback](#)

| Revision | Changes  | Date       |
|----------|--|------------|
| 1.0      | Initial Release  | 2017-02-21 |
| 1.1      | Updated features/part numbers according to FT602Q Rev-B change | 2017-11-23 |



## Стандарт Электрон Связь

Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию .

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России , а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научно-исследовательскими институтами России.

С нами вы становитесь еще успешнее!

### Наши контакты:

**Телефон:** +7 812 627 14 35

**Электронная почта:** [sales@st-electron.ru](mailto:sales@st-electron.ru)

**Адрес:** 198099, Санкт-Петербург,  
Промышленная ул, дом № 19, литера Н,  
помещение 100-Н Офис 331