


1 Verify the Kit Contents


Thank you for purchasing the XBee Wi-Fi Cloud Kit. This kit makes it easy to set up your XBee Wi-Fi hardware and configure the online application. You will be able to see sensor data from your hardware kit on a web page, as well as send data from the web to your device. The components in this kit will allow you to create highly customized solutions.



2 Write Down the MAC Address

Write down the XBee MAC address located on the back of your module.

00409D _____



4 Configure Your Device Using the Wi-Fi Interface

- Use your computer to connect to the Wi-Fi network named 'xbee-xxxxxx'. The 'xxxxxx' represents your XBee's MAC address.
Note: If your XBee module does not show up in the list of available access points, press the Commissioning Button four times to reset it to factory defaults.
- Go to your web browser, and enter the IP address to access the configuration settings for your device: <http://192.168.1.10>
- Navigate to the **Network Access** portion of the configuration page and fill in your local Wi-Fi information.

Note: See the Troubleshooting section in the Getting Started Guide for information on how to troubleshoot your device, which can be found at: www.digi.com/xbeecloudkit.



What's Next ?

Once you have verified the contents of your kit, connected all the hardware, and configured your device to your local access point, please refer to the XBee Wi-Fi Cloud Kit Getting Started Guide which can be found at www.digi.com/xbeecloudkit.



Quick Start Guide


XBee Wi-Fi Cloud Kit



90002196-88 B

3 Connect the Hardware

- Connect the XBee module to the development board.
- Connect one end of the USB cable to the development board and the other end to your computer.



- Once the configuration is complete, click **apply** (located at the bottom of the configuration page). Your device will attempt to connect to your local access point and Device Cloud.

Note: SSID - Your SSID is the name of your local access point and is case sensitive. Your module will use the access point to connect to the internet.

Passphrase - The passphrase is a password or key used to connect to your access point. This is case sensitive.

Encryption Enable - 1 (WPA-TKIP) is a common choice, otherwise set the encryption enable setting to 0 if no passphrase is needed to configure your wireless settings.

Note: The Associate LED on the device will start flashing once you have successfully connected to your local Wi-Fi access point.



Стандарт Электрон Связь

Мы молодая и активно развивающаяся компания в области поставок электронных компонентов. Мы поставляем электронные компоненты отечественного и импортного производства напрямую от производителей и с крупнейших складов мира.

Благодаря сотрудничеству с мировыми поставщиками мы осуществляем комплексные и плановые поставки широчайшего спектра электронных компонентов.

Собственная эффективная логистика и склад в обеспечивает надежную поставку продукции в точно указанные сроки по всей России.

Мы осуществляем техническую поддержку нашим клиентам и предпродажную проверку качества продукции. На все поставляемые продукты мы предоставляем гарантию .

Осуществляем поставки продукции под контролем ВП МО РФ на предприятия военно-промышленного комплекса России , а также работаем в рамках 275 ФЗ с открытием отдельных счетов в уполномоченном банке. Система менеджмента качества компании соответствует требованиям ГОСТ ISO 9001.

Минимальные сроки поставки, гибкие цены, неограниченный ассортимент и индивидуальный подход к клиентам являются основой для выстраивания долгосрочного и эффективного сотрудничества с предприятиями радиоэлектронной промышленности, предприятиями ВПК и научно-исследовательскими институтами России.

С нами вы становитесь еще успешнее!

Наши контакты:

Телефон: +7 812 627 14 35

Электронная почта: sales@st-electron.ru

Адрес: 198099, Санкт-Петербург,
Промышленная ул, дом № 19, литера Н,
помещение 100-Н Офис 331